


JANUARY 1964

NO. 768482

Servicing the

KODAK PAGEANT SOUND PROJECTOR,

MODEL AV-256-TR



EASTMAN KODAK COMPANY
Apparatus Service Department
ROCHESTER, NEW YORK 14650

SERVICE INSTRUCTIONS

KODAK PAGEANT SOUND PROJECTOR, MODEL AV-256-TR

Service information concerning the mechanism of this projector can be found in Service Manual #768376 for the KODAK PAGEANT Sound Projector, Model AV-126-TR. Since the amplifier is different, these instructions cover only the amplifier and power supply.

1. SOUND SYSTEM GENERAL INFORMATION

Transistors:	3 - 2N217 or 2N408 or 2N1370, 1 - 2N1038, 1 - 2N1136, 2 - 2N1136A
Exciter lamp:	6 volt 1.0 ampere, ASA Code BSK
Input impedances:	Microphone, 5,000 ohms; Phono, 0.5 megohms
Output impedance:	16 ohms
Frequency response:	40 to 18,000 cycles $\pm$ 3 db

2. SOUND SYSTEM SERVICE HINTS


See Service Manual #768376 for KODAK PAGEANT Sound Projector, Model AV-126-TR.

3. AMPLIFIER SERVICING

To remove amplifier from the case, refer to Section 5.2 in Service Manual #768376 and to "Switch and Terminal Connections" diagram in this instruction, page 6, for leads to remove.

3.1 Power Supply

Since it is necessary to disconnect only the solar cell lead when removing the amplifier from the case, the amplifier can still be operated and tested, although it may sometimes be convenient to use extension leads to allow easier accessibility. If a separate power supply is required, use a source of DC voltage (with a current capacity of about 750 milliamperes) that will supply a negative 60 to 70 volts measured across the amplifier filter capacitor C-13. Tool #1078 is available for this purpose, or one can be made as shown below, using parts from the amplifier power supply.



1. # 161837 TRANSFORMER

2. # 164193 SILICON RECTIFIER (RCA TYPE IN 3253)
200 PIV, 750 MA

1. # 161832-1500 MFD, 70 VDC, ELECTROLYTIC CAPACITOR

TAPE ENDS OF BLUE AND WHITE AND RED AND WHITE LEADS (NOT USED)

3. AMPLIFIER SERVICING

3.2 Service Hints

- 3.2.1 Although many of the components can be removed and replaced without separating the printed circuit board from the amplifier plate, these operations can be more easily performed if the amplifier is "opened up". To do this, proceed as follows:
- a) Remove the control knobs (tone control-friction fit, volume control - setscrew).
 - b) Remove the four circuit board mounting screws and swing board over.
- 3.2.2 The 50-ohm bias control (R-25) is variable so that the exact value of correct bias may be selected for any given set of transistors. If any of the transistors are replaced, it may be necessary to adjust R-25 to obtain the proper undistorted output (Section 3.3.1).
- 3.2.3 The 25K potentiometer (R-41) is used to compensate for the slight variations in the sensitivity of different solar cells. It will require adjusting only if the solar cell, exciter lamp, or transistors Q1 or Q2 are changed. Adjust to obtain the proper undistorted output (Section 3.3.1).
- 3.2.4 Rotation of the 2.5K frequency response control (R-40) over its full swing will vary the response at 7,000 cycles ± 3 , - 2 db.
- 3.2.5 When replacing either Q6 or Q7 (2N1136 A Transistor) apply a moderate amount of Transistor Z-5 Silicon Compound No. 8101 (General Cement Electronics Company) to both sides of the insulating washers.

3.3 Specifications (input voltage to amplifier, 117)

3.3.1 Output:

- * 17 volts minimum using 400 cycle test film as signal source, no visible distortion on an oscilloscope (a slight amount of "filling-in" may be visible in the lower half of the signal which does not affect the undistorted output).

3.3.2 Sensitivity (tone control fully counterclockwise)

a) Film Channel:

18 watts (*17 volts) output, 1,000 cycle signal of 0.75 millivolts ± 1.5 db applied directly to the solar cell input socket.

b) Microphone Channel:

18 watts (*17 volts) output, 1,000 cycle signal of 22 millivolts ± 3 db applied directly to the microphone input receptacle.

c) Phonograph Channel:

18 watts (*17 volts) output, 1,000 cycle signal of 220 millivolts ± 3 db applied directly to the phonograph input receptacle.

3.3.3 Power Supply:


a) DC voltage to the amplifier:

60 to 70 volts (no load) measured across the filter capacitor C-13.


b) DC voltage to the exciter lamp:

4.0 $\pm$ 0.2 volts with ripple content not exceeding 100 millivolts, RMS, measured across a resistor load of 5 ohms $\pm 1\%$, 5 watts (in place of the exciter lamp).

* Measured across a 16 ohm, 50 watt, dummy speaker load.




VOLTAGE-CHECK AND COMPONENT LOCATING DIAGRAM




R-1	126101	470 K 1/2 WATT $\pm 10\%$	R-25	161829	BIAS CONTROL 50 $\Omega \pm 20\%$	C-8	159413	10 MFD 50 VDC ELECTROLYTIC	CR-1	164193	750 MA 200 PIV DIODE
R-2	78671	47 K 1/2 WATT $\pm 10\%$	R-26	147756	1.8 K 1/2 WATT $\pm 10\%$	C-9	159410	125 MFD 50 VDC ELECTROLYTIC	CR-2	164193	750 MA 200 PIV DIODE
R-3	147756	1.8 K 1/2 WATT $\pm 10\%$	R-27	159427	VOLUME CONTROL 5 K $\pm 30\%$	C-10	165556	25 MFD 50 VDC ELECTROLYTIC	CR-3	164193	750 MA 200 PIV DIODE
R-4	126900	10 K 1/2 WATT $\pm 10\%$	R-28	161830	1 Ω 2 WATT $\pm 5\%$ WIREWOUND	C-11	161831	75 MFD 6 VDC ELECTROLYTIC	CR-4	164193	750 MA 200 PIV DIODE
R-5	136709	47 Ω 1/2 WATT $\pm 10\%$	R-29	161830	1 Ω 2 WATT $\pm 5\%$ WIREWOUND	C-12	159410	125 MFD 50 VDC ELECTROLYTIC	Q-1	166893	TRANSISTOR 2N217 OR 2N408 OR 2N1370
R-6	78671	47 K 1/2 WATT $\pm 10\%$	R-30	159633	25 Ω 25 WATT $\pm 10\%$	C-13	161832	1500 MFD 70 VDC ELECTROLYTIC	Q-2	166893	TRANSISTOR 2N217 OR 2N408 OR 2N1370
R-7	119816	1 K 1/2 WATT $\pm 10\%$	R-31	126394	4.7 K 1/2 WATT $\pm 10\%$	C-14	143229	.0015 MFD $\pm 10\%$ 50 VDC DISC	Q-3	166893	TRANSISTOR 2N217 OR 2N408 OR 2N1370
R-8	126900	10 K 1/2 WATT $\pm 10\%$	R-32	78671	47 K 1/2 WATT $\pm 10\%$	C-15	159416	1500 MFD 50 VDC ELECTROLYTIC	Q-4	162893	TRANSISTOR 2N1038 PNP
R-9	162891	27 Ω 1/2 WATT $\pm 5\%$	R-33	147756	1.8 K 1/2 WATT $\pm 10\%$	C-16	161022	25 MFD 10 VDC ELECTROLYTIC	Q-5	161849	TRANSISTOR 2N1136 PNP
R-10	154866	5.6 K 1/2 WATT $\pm 10\%$	R-34	872378	100 Ω 1/2 WATT $\pm 10\%$	C-17	161022	25 MFD 10 VDC ELECTROLYTIC	Q-6	161835	TRANSISTOR 2N1136A PNP
R-11	162892	33 Ω 1/2 WATT $\pm 5\%$	R-35	161828	18 Ω 1/2 WATT $\pm 10\%$	C-18	159634	1300 MFD 35 VDC ELECTROLYTIC	Q-7	161835	TRANSISTOR 2N1136A PNP
R-12	161824	51 K 1/2 WATT $\pm 5\%$	R-36	126901	6.8 K 1/2 WATT $\pm 10\%$	C-19	159634	1300 MFD 35 VDC ELECTROLYTIC	DS-1		PROJECTION LAMP
R-13	160123	680 Ω 1/2 WATT $\pm 5\%$	R-37	872443	12 K 1/2 WATT $\pm 10\%$	C-20	161020	.005 MFD 50 VDC MIN. CERAMIC	DS-2	120359	PHOTOCELL EXCITER LAMP
R-14	123301	1.1 K 1/2 WATT $\pm 5\%$	R-38	112546	2.7 K 1/2 WATT $\pm 10\%$	C-21	159420	.004 MFD 50 VDC MIN. CERAMIC	S-1	154870	INPUT SELECTOR SWITCH
R-15	126905	27 K 1/2 WATT $\pm 10\%$	R-39	154868	500 Ω 2 WATT $\pm 10\%$ W W	C-22	161021	.0018 MFD 50 VDC MIN. CERAMIC	S-2	159435	TOPE CONTROL SWITCH
R-16	866521	390 Ω 1/2 WATT $\pm 10\%$	R-40	161857	CONTROL-FREQUENCY RESPONSE 2.5 K	C-23	161021	.0018 MFD 50 VDC MIN. CERAMIC	S-3	159533	PROJECTOR CONTROL SWITCH
R-17	872379	12 K 1/2 WATT $\pm 10\%$				C-24	159418	100 MFD 50 VDC MIN. CERAMIC	S-4	159445	AMPLIFIER CONTROL SWITCH
R-18	165557	600 Ω 5 WATTS $\pm 5\%$ W W	C-1	161022	25 MFD 10 VDC ELECTROLYTIC	C-25	159409	.027 MFD 100 VDC MIN. MYLAR	J-1		THREADLAMP SOCKET
R-19	161827	91 Ω 1 WATT $\pm 5\%$	C-2	161022	25 MFD 10 VDC ELECTROLYTIC	C-26	159414	.033 MFD 100 VDC MIN. MYLAR	CB-1	151383	CIRCUIT BREAKER
R-20	127852	300 Ω 5 WATT $\pm 10\%$ W W	C-3	161858	.015 MFD 50 VDC MYLAR	C-27	159419	.047 MFD 100 VDC MIN. MYLAR	T-1	161836	DRIVER TRANSFORMER
R-21	872443	12 K 1/2 WATT $\pm 10\%$	C-4	161022	25 MFD 10 VDC ELECTROLYTIC	C-28	164758	40 MFD 25 VDC ELECTROLYTIC	T-2	166437	POWER TRANSFORMER
R-22	126900	10 K 1/2 WATT $\pm 10\%$	C-5	164758	40 MFD 25 VDC ELECTROLYTIC	C-29	159413	10 MFD 50 VDC ELECTROLYTIC	P-1	159551	POWER CORD
R-23	161828	18 Ω 1/2 WATT $\pm 10\%$	C-6	161022	25 MFD 10 VDC ELECTROLYTIC	C-30	164757	.001 MFD $\pm 10\%$ 50 VDC MIN. CERAMIC	R-41	164603	25 K POTENTIOMETER
R-24	126900	10 K 1/2 WATT $\pm 10\%$	C-7	159413	10 MFD 50 VDC ELECTROLYTIC	C-31	164757	.001 MFD $\pm 10\%$ 50 VDC MIN. CERAMIC	R-42	154868	500 Ω 2 WATTS $\pm 10\%$ W W

AMPLIFIER SCHEMATIC CIRCUIT



- * DISCONNECT TO REMOVE AMPLIFIER (AMPLIFIER WILL STILL OPERATE)
- ▲ DISCONNECT TO REMOVE AMPLIFIER COMPLETELY
- DISCONNECT TO REMOVE MECHANISM

SWITCH AND TERMINAL CONNECTIONS (March 1963)



APRIL 1963

NO. 768376

Servicing the

Kodak Pageant Sound Projector, Model AV-126-TR



EASTMAN KODAK COMPANY
Apparatus Service Department
ROCHESTER 4, NEW YORK

T A B L E O F C O N T E N T S

KODAK PAGEANT SOUND PROJECTOR, MODEL AV-126-TR

	Page
1. GENERAL SPECIFICATIONS	3
1.1 Electrical	
1.2 Mechanism	
1.3 Sound System	
2. SERVICE HINTS	3 - 4
2.1 Mechanism	
2.2 Sound System	
3. SERVICE LUBRICANTS	5
4. SPECIAL TOOLS AND TEST FILMS	5
5. HOW TO:	5 - 26

	<u>Remove</u>	<u>Install</u>	<u>Adjust</u>	
5.1	X	X		Mechanism
5.2	X	X		Amplifier
5.3	X	X	X	Aperture Plate and Pressure Pad Assembly
5.4	X	X		Sprockets
5.5	X	X		Upper Sprocket Hub
5.6	X	X		Lower Sprocket Hub
5.7	X	X	X	Upper Sprocket Clamp
5.8	X	X	X	Lower Sprocket Clamp
5.9	X	X	X	Damper Roller Arm and Spring
5.10	X	X	X	Exciter Lamp Bracket
5.11	X	X	X	Chain
5.12	X	X	X	Planetary Gear Assembly and Rewind Mechanism
5.13	X	X		Lower Sprocket Gear
5.14	X	X		Sound Drum and Sprocket & Pawl Assembly
5.15	X	X	X	Flywheel
5.16	X	X	X	Pressure Roller Assembly
5.17	X	X	X	Shutter Drive Belt
5.18	X	X	X	Pull-Down Mechanism
5.19	X	X		Super-40 Shutter
5.20	X	X		Shutter Shaft and Ball Bearing
5.21	X	X		Control Switch
5.22	X	X	X	Speed and Direction Control Mechanism
5.23	X	X		Motor
5.24	X	X		Take-Up Arm
5.25		X		Take-Up Spindle
5.26	X	X		Supply Spindle and Pulley
5.27	X	X		Elevating Mechanism
5.28	X	X		Silicon Solar Cell Mount and Cable Assembly
5.29			X	Lamp Socket
5.30			X	Sound System (Optics and Related Area)

	Page		Page
6. AMPLIFIER SERVICING		7. SCHEMATIC AND WIRING DIAGRAMS	
6.1 Printed Circuits, General	27	7.1 Power Supply and Master Control Switch	30
6.2 Transistorized Circuits, General	28	7.2 Switch and Terminal Connections	31
6.3 Servicing the AV-126-TR Amplifier	28	7.3 Voltage Check and Component Locating	32
6.3.1 Power Supply	28	7.4 Schematic Circuit	33
6.3.2 Service Hints	29	7.5 Amplifier Wiring	34
6.3.3 Specifications	29	7.6 Component Board	35

SERVICE INSTRUCTIONS
KODAK PAGEANT SOUND PROJECTOR, MODEL AV-126-TR

1. GENERAL SPECIFICATIONS

1.1 ELECTRICAL

Power service required: 105 to 125 volt, 60 cycle ac only

Power consumed: with 750 watt lamp - 950 watts
with 1000 watt lamp - 1200 watts
with 1200 watt lamp - 1400 watts

Projection lamps: 750 watt, ASA Code DDB
1000 watt, ASA Code DFD
1200 watt, ASA Code DHT

1.2 MECHANISM

Claw protrusion: .030" - .045" (Section 5.18.3).
Pull-through tension: $1\frac{1}{2}$ - $2\frac{1}{2}$ ounces (Section 5.3.4).
Side guide tension: 1 - $1\frac{1}{2}$ ounces (Section 5.3.2).
Flywheel torque: 3 - $4\frac{1}{2}$ ounce-inches (Section 5.15.3).
Pressure roller tension: 12 - 18 ounces.
Shutter shaft RPM, Sound Speed: 1440 ± 75
Shutter shaft RPM, Silent Speed: between 1020 and 1140

1.3 SOUND SYSTEM

Transistors: 5-2N109 or 2N1370, 2-2N307 or T1-370, 1-2N35 or 2N1304
Exciter lamp: 6 volt 1.0 ampere, ASA Code BSK
Input impedances: Microphone, 5,000 ohms; Phono, 0.5 megohms
Output impedance: 6 ohms
Frequency response: 30 to 20,000 cycles $\pm$ 3 db

2. SERVICE HINTS WITH SUGGESTED CHECK POINTS

2.1 MECHANISM

Projector will not run forward

Motor drive pulley belt slippage caused by oil on belt.
Clean oil off pulleys and replace belt.
Direction shifting adjustment (Section 5.22.5).
Shutter drive belt slippage.

Projector will not run in reverse

Motor drive pulley slippage caused by oil on rubber drive. Replace pulley.
Direction shifting adjustment (Section 5.22.5).
Shutter drive belt slippage.

Speed shifting operates improperly

Speed shifting adjustment (Section 5.22.3).
Speed shifting lever assembly (Section 5.22). If Type I, II, or III as described in Section 5.17 - replace parts as described.

Supply spindle binds - "A" serial number projectors

Replace complete supply reel arm assembly with late style #160722.

Streaks on screen - no film in projector

Projection lamp seating and adjustments (Section 5.29.1).
Condenser mount assembly.
Reflector.

Picture does not focus properly

Free movement of projection lens field flattener element.
Alignment of the aperture plate and pressure pad assembly (Section 5.3.2).

Picture cannot be framed properly

Stripped threads on framing shaft.
Framing shaft retaining ring missing.

Picture unsteady

Claw clearance in aperture plate slot (Section 5.3.4).
Pull-through tension (Section 5.3.4).
Free movement of side guides.
Side guide pressure (Section 5.3.2).
Cam follower.
Shutter shaft ball bearing.

Projector loses lower loop and tears film perforations

Claw clearance in aperture plate slot (Section 5.3.4).
Claw protrusion (Section 5.18.3).
Alignment of pressure pad rails with aperture plate rails (Section 5.3.2).
Pull-through tension (Section 5.3.4).
Sound drum pressure roller tension (Section 5.16.3).
In-and-out cam wear.
Cam follower wear.

Breaks splices

Condition of splices.
Excessive amount of pull-through tension (Section 5.3.4).
Sprocket clamp adjustment (Section 5.7.3 upper; Section 5.8.3 lower).

Does not take-up film

Take-up pulley pawl binds (Section 5.25.1).
Take-up belt.

Super-40 shutter fails to shift or shifts slowly

Locking lever action.
Blades bind (Section 5.19.2).
Shutter weight return spring tension.

Take-up (rear) reel spills film while projector is running in reverse

Take-up pulley assembly binds (Section 5.25.1).
Clean and lubricate the pulley pawl.

Spills film off supply (front) reel while projector is running in reverse

Supply spindle torque. Correct torque is between 7 and 14 ounce-inches. If torque is low, replace the tension adjusting spring #131363.

Film does not stay on sound drum when projector is running in reverse

Damping roller arm adjustment (Section 5.9.3).

Rewind does not function

Rewind belt.
Rewind mechanism.
Take-up and rewind spindles bind.
"A" serial number projectors - replace complete supply reel arm assembly with late style #160722.

Scratches film

Damper roller or sound drum pressure roller binds.
Rough or worn rails on pressure pad.
Alignment of pressure pad rails with aperture plate rails (Section 5.3.2).
Burr, nicks, or abrasions on all surfaces over which film passes.

Supply (front) spindle rotates while projector is running forward, without film

Clearance between the sun gear and sprocket and the reversing mechanism internal gear (Section 5.12.3).

Film noise in gate

Excessive amount of pull-through tension (Section 5.3.4).
Clearance of claw in aperture plate slot (Section 5.3.4).

Mechanism noisy - no film in projector

Claw clearance in aperture plate slot (Section 5.3.4).
Claw protrusion (Section 5.18.3).
Claw return spring.
Claw retaining spring.
Pull-down cam.
In-and-out spring.
Shutter shaft bearings and ball bearing retaining screws.
Worm secure on shutter shaft.
Fan clearance in fan housing.
Tightness of fan housing-to-mechanism mounting screws.
Tightness of mechanism-to-case mounting screws.
Speed shifting adjustment (Section 5.22.3).
Motor bearings worn.
Belt damping rollers - "A" serial number projectors - modify projector using Kit #K-1655 (Section 5.17).

Pinging sound in mechanism, especially at silent speed

Drive belt operation.
Speed shifting adjustment (Section 5.22.3).

Motor noisy

Worn motor bearing.

Projector speed incorrect

Motor drive pulley belt and rubber drive slippage caused by oil on belt and/or rubber drive. Replace pulley and/or belt.
"A" serial number projector fit oil catcher #165193 and clip #164853 on end of motor shaft.

2.2 SOUND SYSTEM

No film sound (exciter lamp not lighted)

Exciter lamp connection to power supply.
Power supply.
Exciter lamp.

No film sound (exciter lamp lighted)

Plug in microphone and

1. If no sound through microphone, check amplifier.
2. If sound satisfactory through microphone, check following:
 - Threading of projector
 - Speaker plug contact
 - Speaker cable continuity
 - Sound optics adjustment (Section 5.30.1)
 - Solar cell cable and connection

Excessive hum

Solar cell cable plug connection.

Noise in speaker

Sound drum reverse drive chain (Section 5.11.3).
Projector electrical connections.
Electrical leakage between motor frame and projector
or between amplifier and projector.
Fan clearance.
Motor grounding connection.

Microphonics

Seating of the exciter lamp in the socket.
Sound optics adjustment (Section 5.30.1).

Microphonics (microphone plugged in)

Microphone.
Microphone connector.

Weak or distorted sound

Fidelity control adjustment, (see projector instruction
book).
Seating of exciter lamp in the socket.
Sound optics assembly and sound optics adjustment,
(Section 5.30.1).

Speaker rattles at high sound volume

Speaker coil bottoming.
Speaker cone.

Sound unsteady

Threading of projector.
Damping roller action (Section 5.9.3).
Sound drum binds.
Sound drum reverse drive chain (Section 5.11.3).
Pressure roller action (Section 5.16.3).
Pressure roller tension (Section 5.16.3).
Lower sprocket.
Damping roller spring tension (Section 5.9.3).
Damping fluid in damping bearing cup (Section 5.9.2).

Sound still unsteady after above checks

Sound drum ball bearing roughness.
Binds in sound drum sprocket and pawl assembly.

Fidelity control does not peak

Positioning and adjustment of sound optics assembly -
(Section 5.30.1).
Sound optics.

3. SERVICE LUBRICANTS

Available from:

EASTMAN KODAK COMPANY
APPARATUS PARTS SERVICE
ROCHESTER 4, NEW YORK

Or others as indicated:

A&O10-592 - Special Formula Lubricant

A&O61-3619 (CW6782) - Special Formula Lubricant

EK1150 Oil equivalent to:

Sunvis No.916 (Sun Oil Co.)
Teresso No.43 (Esso)
Pacemaker 150T (Cities Service)
Harmony "A" (Gulf Oil Co.)
Turbo No.27 (Shell Oil Co.)

A&O61-3655 (CW8362) - Grease

Plastilube No.1 (Warren Refining and Chemical Co.,
Cleveland, Ohio).

A&O61-3664 (CW6092) - Grease

Texaco Unitemp (Texas Co.)

A&O61-3778 - Lubricant - Microfine Molykote

A&O61-3834 - Oil - Lubriplate No.1 Oil

EK110882 - Fluid

DC No.200 - 100,000 centistokes (Dow Corning)

NOTE: Lubrication is normally required only when
projector is serviced, periodic lubrication is not
necessary. For details refer to installation instruction
in the section for the particular part or assembly.

4. SPECIAL TOOLS & TEST FILM

No.260 - Spring Tension Scale
No.1007 - Claw Depth Gauge
No.1034 - Power Supply
No.760079 - SMPTE "JIFFY" Test Film
No.760382 - 6 foot loop - SMPTE 5,000 Cycle Sound
Focusing Test Film
No.760383 - SMPTE Buzz Track Test Film
No.760386 - 6 foot loop - SMPTE 400 Cycle Signal
Level Test Film
No.761715 - 25 feet SMPTE Registration Test Film

5. HOW TO


5.1 MECHANISM

5.1.1 Remove




- Two screws (1), screw and spacer (2), control knob (setscrew), than take off exciter lamp cover.
- Cord compartment baffle (2 screws).
- Mechanism support bracket located beneath the baffle (2 screws in case back). - (continued)

5.1.1 Remove Mechanism (continued)



- d) Leads shown in drawing.
e) Screw on bottom of case.



- f) Four screws (arrows) and lift mechanism out of case.
g) Support post, to stand mechanism upright.

5.1.2 Install

Mechanism in reverse order of removal. Lubricate the film guide roller shafts on the exciter lamp cover with EK1150 Oil as required.

5.2 AMPLIFIER


5.2.1 Remove

- a) Exciter lamp cover and cord compartment baffle, (Section 5.1.1).
b) Solar cell plug from jack.



- c) Four amplifier mounting screws (arrows).
d) Amplifier from case - manipulate wires as needed.

NOTE: Amplifier can now be operated and tested.



- e) Leads shown in drawing to completely remove amplifier from case.



5.2.2 Install - amplifier in reverse order of removal.

5.3 APERTURE PLATE AND PRESSURE PAD ASSEMBLY



5.3.1 Remove

- a) Pressure pad.
- b) Aperture plate (2 screws).

5.3.2 Adjust



- a) Pressure of movable side guides (1) between 1 and 1½ ounces by bending spring (2).



framing knob turned to the extreme clockwise position and then to the extreme counterclockwise position. If either claw point strikes either side of the film perforations or the claw slot, loosen the two aperture plate screws and re-position the plate.


- b) Pressure pad rails to align with aperture plate rails (1); if necessary, loosen screws (2) to re-position pressure pad.

5.3.3 Install - parts in reverse order of removal.

5.3.4 Adjust

- a) Clearance of pull-down claw in aperture plate slot as follows:


Place a strip of film in the gate. Turn the threading knob and observe the claw action with the



- b) Pull-through tension (between 1½ and 2½ ounces) with claw retracted, using a strip of processed black-and-white film in the gate. Turn screw (1) clockwise to increase and counterclockwise to decrease. Apply a small amount of air-drying cement to the screw.

5.4 SPROCKETS


5.4.1 Remove



End plate screws (1), end plate (2), and sprocket (3), note spring behind upper sprocket.

5.4.2 Install (lubricate outside diameter of upper sprocket drive collar with A&O61-3834 Oil).

- a) Spring in upper hub with point of spring in the hole of the collar then rotate hub clockwise to the stop and hold in this position




- b) Upper sprocket in the hub with the end of the spring engaging hole in sprocket, then rotate sprocket counterclockwise to align screw holes.
c) End plate and screws - end plate should be centered for appearance.
d) Lower sprocket, end plate and screws.


5.5 UPPER SPROCKET HUB

5.5.1 Remove

- a) Upper sprocket and spring (Section 5.4.1).



- b) The two upper sprocket plate retaining screws (1) and the spacer (2), then lift off the assembly.



- c) Collar (1) (by removing setscrew (2) through hub) stud (3) and hub (4).

NOTE: It may be necessary to drive the shaft out in order to remove the collar (1) and hub (4).

5.5.2 Install

- a) Hub on shaft, then the stud and collar in the hub so that the cut-out of collar is over the stud.
b) Setscrew in collar and tighten setscrew on cut-out of shaft; no end play.
c) Upper sprocket plate assembly on projector. Be sure belt is in place. Hold assembly firmly in a downward position while installing spacer and screw to insure that take-up belt is properly engaged.
d) Sprocket and spring (Section 5.4.2).

5.6 LOWER SPROCKET HUB

5.6.1 Remove

- a) Mechanism from case (Section 5.1.1).
b) Lower sprocket (Section 5.4.1).
c) Hub by removing setscrew and shaft.


5.6.2 Install

- a) Hub on shaft and tighten setscrew on cutout of shaft; no end play.
b) Lower sprocket (Section 5.4.2).
c) Mechanism in case (Section 5.1.2).

5.7 UPPER SPROCKET CLAMP

5.7.1 Remove

- a) Upper sprocket clamp (Section 5.5.1. b).



- b) Sprocket clamp parts as required.


5.7.2 Install parts in reverse order of removal. Lubricate the sprocket guard stop pin ball with EK1150 Oil; the roller shafts with A&O61-3664 Grease and the sprocket shaft with A&O61-3834 Oil.

5.7.3 Adjust sprocket clamp, using two and three thicknesses of film. With clamp closed, rollers should turn freely with two thicknesses of film, but should be snug with three. Carefully bend post on plate to accomplish this.

5.8 LOWER SPROCKET CLAMP

5.8.1 Remove

- a) Lower sprocket hub (Section 5.6.1).
- b) Lower sprocket plate assembly (2 screws).



- c) Sprocket clamp assembly parts as required.

5.8.2 Install parts in reverse order of removal - (Section 5.6.2 for hub installation). Lubricate as follows:

- a) Sprocket guard stop ball and idler roller shaft with EK1150 Oil.
- b) Sprocket roller shafts and idler arm pivot pin with A&O61-3664 Grease.


5.8.3 Adjust

Sprocket clamp using two and three thicknesses of film. With clamp closed, rollers should turn freely with two thicknesses of film, but should be snug with three. Loosen screws and move plate assembly to make this adjustment.

5.9 DAMPER ROLLER ARM AND SPRING

5.9.1 Remove

- a) Lower sprocket clamp (Section 5.8.1).




- b) Damper roller parts as required.

5.9.2 Install (lubricate roller shaft and bearing with EK1150 Oil, and use EK110882 Fluid as required in bearing cup.)

- a) Parts in reverse order of removal - adjustment (Section 5.9.3a) can be made at this point.
- b) Lower sprocket clamp on projector (Section 5.8.2) and adjust clamp (Section 5.8.3).


5.9.3 Adjust



- a) Tension on damping roller arm, using a small blade screwdriver or scribe through slot (1) to move spring lever. When the damping roller (2) is in the relaxed position, there should be no tension on the damping roller spring.

- b) Damping roller arm as follows:


Remove the damping roller retaining screw. Thread the projector for sound, using processed film; turn on the motor and observe the action of the damping roller. A correctly adjusted roller arm will cause the damping roller to work its way off the shaft slowly when the projector is running forward and cause it to work its way on the shaft slowly (toward the sprocket plate) when the projector is running in reverse. If the roller motion is rapid in either direction, it indicates that the roller arm is bent too much and should be straightened till the IN and OUT movement of the roller is slow. Do not bend the roller arm in the direction "C-D"; bend as indicated by "A-B". Replace the damping roller retaining screw.




5.10 EXCITER LAMP BRACKET

5.10.1 Remove

- a) Mechanism from case (Section 5.1.1).
- b) Sound optics by unhooking the mount spring from the bracket assembly.



- c) The exciter lamp wire (blue) from the power supply terminal strip. Loosen the sound optics bracket spring screw (1) and move the bracket spring (2) to the side far enough to allow removal of the bracket.



- d) Bracket by removing clamp screw (1), eccentric screw (2) and eccentric (3).

5.10.2 Install parts in reverse order of removal.

5.10.3 Adjust centering of scanning beam - see sound system "Optics and Related Area" (Section 5.30.1).

5.11 CHAIN


5.11.1 Remove

- a) Mechanism from case (Section 5.1.1).
- b) Reverse take-up clutch actuator (1).
- c) Chain after loosening screw (2) and moving tension adjustment stud (3) to allow sufficient slack in chain to bring it over the sprocket teeth.

5.11.2 Install parts in reverse order of removal. To install a new chain, carefully open a link, place chain on sprockets, close link and replace adjustment stud (3) if previously removed. Lubricate the chain, tension adjusting stud, and reverse take-up clutch bushing (4) with EK1150 Oil.

5.11.3 Adjust




Tension adjustment stud (3) so that there is a slight amount of slack in the chain. Too tight an adjustment will result in "wows" in the sound; too loose a chain will allow it to strike the pivot shaft (5) when the projector is elevated, causing static in the sound.



5.12 PLANETARY GEAR ASSEMBLY AND REWIND MECHANISM

5.12.1 Remove

- a) Chain (Section 5.11.1).



- b) Sun gear (1) by loosening setscrew (2), then spider (3) and planetary gears (4).
c) Adjustment stud (5).
d) Shift plate shaft (6) and spacing washer (7) by loosening screw (8).
e) Reverse mechanism gear (9), shift plate (10) and pulley (11).
f) Sprocket shaft and gear assembly (12), if necessary, by removing sprocket hub (Section 5.5.1).

5.12.2 Install parts in reverse order of removal; lubricate as follows:

- a) All gear teeth, and actuator groove on the sun gear (1) with EK1150 Oil.
b) Upper sprocket drive shaft with A&O61-3834 Oil.
c) Rewind shaft lever detent spring and shift plate pivot with A&O61-3619 Lubricant.
d) Tension clutch groove on spider (3) with A&O10-592 Lubricant.

5.12.3 Adjust

Clearance between sun gear and sprocket (1) and the reversing mechanism internal gear (9); this should be established by setting the sun gear and sprocket tightly against the internal gear and then backing the gear off the shaft .015" to .020".

NOTE: Adjust chain (Section 5.11.3) and sprocket clamp (if previously removed Section 5.7.3).

5.13 LOWER SPROCKET GEAR

5.13.1 Remove


- a) Chain (Section 5.11.1).
- b) Lower sprocket hub (Section 5.6.1).
- c) Lower sprocket gear and shaft.

5.13.2 Install parts in reverse order of removal.
Lubricate gear teeth with EK1150 Oil.

5.14 SOUND DRUM AND SPROCKET & PAWL ASSEMBLY

5.14.1 Remove

- a) Flywheel and spacer behind flywheel - (Section 5.15.1).



- b) Retaining ring (1), note washer (2) between the ring and the sprocket.
- c) Sound drum shaft by:
 1. Loosening setscrew (3) in ratchet.
 2. Holding back on pressure roller while shaft is withdrawn to the second retaining ring.
 3. Removing second retaining ring and withdrawing shaft.


5.14.2 Install parts in reverse order of removal.

Lubricate the shaft, pawl, and ratchet with EK1150 Oil.
Make necessary adjustments to chain (Section 5.11.3) and flywheel (Section 5.15.3).

5.15 FLYWHEEL

5.15.1 Remove


- a) Mechanism from case (Section 5.1.1).



- b) Flywheel nut (1), (left hand thread), spacer washer (2), spring washer (3) and phenolic washer (4).
- c) Flywheel (5) and spacer (6).

5.15.2 Install (lubricate the shaft at the flywheel with A&O61-3619 Lubricant).

- a) Spacer (6) and flywheel (5).
- b) Phenolic washer (4).
- c) Spring washer (3), concave side next to flywheel, spacer washer (2) and nut (1), (left hand thread).




5.15.3 Adjust

Flywheel slipping torque; between 3 and 4 ½ ounce inches. Check by hooking a pull-type spring scale in one of the holes in the flywheel. Keep the axis of the scale at a right angle to a radial line from the center of the flywheel to the point of the contact of the spring scale. Hold the sound drum firmly to prevent shaft from turning and note the tension required to start the flywheel rotating. A correctly adjusted flywheel will require between 3 and 4 ½ ounces of tension when the torque is measured in this way.

5.16 PRESSURE ROLLER ASSEMBLY

5.16.1 Remove

- a) Sound drum (Section 5.14.1).
- b) Pressure roller (1) by pushing back on the equalizing link (2) and removing the shaft (3). See illustration of rear view of assembly showing relative position of arm, link, and spring (4).
- c) Arm assembly (5) by turning the hexagon spacer (6) counterclockwise.




5.16.2 Install

- a) Arm assembly and pressure roller. Apply a light film of A&O61-3664 Grease to the roller shaft and the pivot.
- b) Sound drum shaft (temporarily).


5.16.3 Adjust

Pressure of roller against sound drum, if necessary. The pressure should be 12 to 18 ounces. If too great, stretch spring (4) on equalizing link.



5.16.4 Install

Sound drum shaft, ratchet, sprocket and pawl, and balance of parts in reverse order of removal. Apply a light film of EK1150 Oil to sound drum shaft, ratchet and pawl. Make necessary adjustments to chain (Section 5.11.3) and to flywheel (Section 5.15.3).








5.16.5 Adjust

Position of pressure roller, using buzz track test film, (Section 5.30.1 b).

5.17 SHUTTER DRIVE BELT

The belt shifting rollers and belt damping systems vary on these projectors and since the new belt requires a different shutter drive pulley and no damping it is necessary to modify the older style projectors. This modification, as well as the parts required, varies depending upon the style used in the projector.




(continued)


5.17 SHUTTER DRIVE BELT (Continued)

5.17.1 Remove


- a) Mechanism from case (Section 5.1.1).
- b) Lamphouse cover and projection lamp.



- c) Three fan housing screws (1), the spacer (2), and lockwasher. (Power supply has been removed for illustration only).
- d) Fan housing (4) and fan by loosening fan setscrew through access hole (5).



- e) Lamp chimney by removing the four screws (1).
- f) Drive belt.



g) Type I

1. Remove and discard the shutter drive arm and pulley assembly by disconnecting the link (1) and removing the two mounting screws (2).
2. Remove and discard the two eccentric belt shifting rollers.
3. Remove and discard the two belt damping rollers. One located on the fan housing cover plate, the other on the mechanism casting.

h) Type II

1. Remove and discard the shutter drive arm and pulley assembly by disconnecting the link (1) and removing the two mounting screws (2).
2. Remove and discard the two eccentric belt shifting rollers.
3. Remove and discard the two belt damping brushes. Some of the brushes are held on with screws; others are riveted and will have to be broken off without damaging the roller shafts.

i) Type III


1. Remove and discard the shutter drive arm and pulley assembly by disconnecting the link (1) and removing the two mounting screws (2).
2. Remove and discard the two belt damping brushes. Some of the brushes are held on with screws, others are riveted and will have to be broken off without damaging the roller shafts.

j) Types IV and V

No further disassembly necessary.



KIT #K-1655 SHUTTER DRIVE BELT AND SHIFTING ROLLER KIT



USE WITH STRAIGHT ROLLER 126200



USE WITH ECCENTRIC ROLLER 153360

5.17.2 Install

- Types I, II, and III - new shutter drive arm and pulley assembly #160718.
- Types I and II - new rollers #153360 and #126200. (Extra springs and washers provided in Kit #K-1655, in case of loss or damage while removing original parts). Note coil direction of springs.
- All Types - new shutter drive belt.

5.17.3 Adjust speed shifting, Types I, II, and III as follows:


- Bend bracket down at "A" so that rollers just clear pulley.
- With shifting lever in sound speed and belt on high side of pulley, bend bracket at "B" so that black roller barely clears the belt.
- With shifting lever in silent position and belt on low side of pulley, bend bracket at "B" so that eccentric roller clears belt by .010"-.020" when high side of eccentric is away from belt.
- When adjusted correctly, shifting can be accomplished while rotating the mechanism by hand.
- Types IV and V should normally require no adjustments, but if required, follow the above procedure.

5.17.4 Install


Balance of parts to projector and fit into the case.

5.18 PULL DOWN MECHANISM


5.18.1 Remove




- a) Drive belt (1) (Section 5.17.1 a thru f), shutter shaft nut (2) (left hand thread), and washer.
- b) Super-40 shutter - see Section 5.19 for detailed service information.



- c) In-and-out cam (1), and up-and-down cam (2) - note shim washers behind the up-and-down cam.
- d) Claw return spring (3).
- e) Retaining spring (4) by removing screw (5).



- f) Pad (1), ball (2), and pull-down claw (3).



- g) Pad (1), balls (2).

5.18.2 Install

- a) Pull-down parts in reverse order of removal, applying lubricants as follows (see preceding illustrations):

L-1 EK1150 Oil - moisten both pads - light film on surface of up-and-down cam.

L-2 A&O61-3655 Grease - contact points of return spring with framing lever and claw assembly. Little on in-and-out spring, where small button on claw assembly bears against the spring.

L-3 A&O61-3619 Lubricant - small amount on three pivot balls and in ball recesses.

- b) Super-40 shutter temporarily. Make sure that timing lug of shutter is in the aligned holes of the cam. (See Section 5.19 for detailed service information on Super-40 Shutter).

5.18.3 Adjust

- a) Claw clearance (Section 5.3.4a).
- b) Claw protrusion. The top claw should extend through the film perforation, but not so far that it strikes the frame of the pressure pad assembly on the pull-down stroke or touches the film on the return stroke. (Factory adjustment is .030" - .045" beyond aperture plate rails.) Correct, if necessary, by changing the total thickness of claw shim washers.



5.18.4 Install

- a) Super-40 shutter finally. The fixed blade of the shutter should be away from the aperture when the line on the threading knob is towards the operator. (See Section 5.19 for detailed service information on Super-40 Shutter).
- b) Balance of components in reverse order of removal.

5.19 SUPER-40 SHUTTER


5.19.1 Remove

Super-40 shutter from projector -(Section 5.18.1 a thru c). Shutter can now be disassembled as required.



5.19.2 Install as follows:

- Place the locking lever (1) in the lock position and assemble the inner (2) and outer (3) blades to the shutter frame (4). The inner blade can be identified by the small bumps around the center.
- Make sure that the actuating studs (5) and stop studs (6) are positioned as shown. Assemble the cam (7) to the shutter, with the timing lug (8) engaging the timing hole (9).





- Rotate the cam to position the timing hole at the top. Tilt the mechanism slightly back and holding the assembled shutter as shown, sneak up on the shutter shaft, making sure that the timing lug (1) of the shutter engages the timing holes (2) of the cams. Replace the washer and shutter shaft nut (left hand thread). Do not tighten the nut.
- Move the lever to the unlocked position and manually check the shutter blades for freedom of movement. If there is any binding, recheck for proper assembly of the various parts. If shutter action is satisfactory, proceed with final orientation.
- Final orientation - remove the threading knob. The flat side of the shutter shaft should face away from the lens holder casting when the shutter timing lug is toward the aperture. If it is not, hold the shutter to keep it from moving and turn the shutter shaft until the flat side of the shaft is correctly positioned. Hold the shaft with a suitable wrench and tighten the shutter nut (left hand thread).
- Recheck the shutter blades for freedom of movement. Replace the threading knob.
- Lubricate weight and blades with small amount of A&O61-3778 Lubricant as required.

5.20 SHUTTER SHAFT AND BALL BEARING

5.20.1 Remove

- Planetary gear assembly (Section 5.12.1 a thru e).
- Pull-down parts (Section 5.18.1 a thru d).
- Shim washers



- Ball bearing retaining screws and lockwashers (1). Loosen 2 setscrews (2) 180 degrees apart, in worm (3).
- Shutter shaft (4) and ball bearing (5) by pulling shaft from pull-down side. (Exploded view shows worm, shutter, shaft, retaining ring (6), and ball bearing).

5.20.2 Install


Parts in reverse order of removal, making sure that worm is centered (see also Section 5.18.2 and 5.18.4). Make necessary adjustments to planetary gear assembly (Section 5.12.3), and chain (Section 5.11.3).

5.21 CONTROL SWITCH


5.21.1 Remove

- Exciter lamp cover (Section 5.1.1a).
- All wire connections from switch.
- Switch by loosening setscrew in cam, sliding cam up (out of mesh), loosening switch retaining nut, and sliding switch down and out.

5.21.2 Install



- Switch and nut in bracket and tighten nut.




- Cam in mesh with control lever so that conditions in drawing are met.
- Switch connections (see Master Control Switch - page 30), and reassemble projector.
- Lubricate following points with A&O61-3655 Grease:
 - Teeth and cam of switch cam and pinion.
 - Pivot area of projector control lever.
 - Pivot area of projector switch cam yoke.
 - Shifting arm stud.
 - Contact points of interlock lever.

5.22 SPEED AND DIRECTION CONTROL MECHANISM


See Section 5.17 for illustrations of the various types of speed shifting lever assemblies.

5.22.1 Remove


- a) Motor (Section 5.23).
- b) Switch connections.



- c) Stud holding pulley shifting lever to pulley arm by removing nut and lockwasher (1).
- d) Pulley assembly by removing screws (2) and eccentric (3).




- e) Belt shifting lever eccentric by removing screw and lockwasher (1).
- f) Toggle levers (2).



- g) Two hex socket head cap screws (1) holding shifting assembly to casting.
- h) Shifting assembly by loosening screw (2) and manipulating assembly.
- i) Parts from assembly as required.


5.22.2 Install

- a) Shifting assembly on projector.
- b) Mounting screws (1) and (2) loosely.



- c) Pulley assembly eccentric and screws (2 & 3).
- d) Stud holding pulley shifting lever to pulley arm, nut, and lockwasher (1). (continued)

5.22.2 Install (continued)




e) Belt shifting lever eccentric (1) (screw and lockwasher) and toggle levers (2).


5.22.3 Adjust speed shifting assembly by positioning the assembly and rotating lever eccentric so that:

- Shifting can be accomplished only in the forward position of the control lever.
- Drive belt does not touch either shifting roller in sound or silent speed.
- Shifting rollers do not touch pulley.
- Speed shifting can be accomplished while rotating mechanism by hand.


5.22.4 Install motor and switch connections.



FORWARD



REVERSE



5.22.5 Adjust forward and reverse shifting by moving toggle lever (loosen screw (1)) and rotate drive pulley eccentric so that:

- Belt drives mechanism in forward direction.
- Rubber drive on motor pulley drives mechanism in reverse direction.
- Drive belt is slack and rubber drive does not contact pulley in "OFF" position.
- Above three conditions are met under any operating situation. Lubricate speed shifting rollers with A&O61-3778 Lubricant.

5.23 MOTOR

5.23.1 Remove

- Mechanism from case (Section 5.1.1).
- Motor by loosening setscrews in pulley and fan, and by removing three motor mounting screws. Note grounding spring on one of the screws.


5.23.2 Install parts in reverse order of removal - be sure setscrews are on flat of motor shaft and the pulleys are centered.

5.24 TAKE-UP ARM

5.24.1 Remove

- Mechanism from case (Section 5.1.1).
- Arm assembly by removing two screws holding it to the casting.
- Parts as required, (see breakdown below).

5.24.2 Install parts in reverse order of removal. Lubricate the arm spindle, pivot, and release lever pivot with A&O61-3834 Oil.




5.25 TAKE-UP SPINDLE

5.25.1 Install (see breakdown below).

Lubricate the following points with A&O61-3834 Oil:

- Spindle pawl pivot.
- Inside diameter of pulley ratchet.
- Spindle.



5.26 SUPPLY SPINDLE AND PULLEY


5.26.1 Remove

- a) Belt from pulley.
- b) Pulley from spindle by driving out pin.
- c) Spindle by carefully withdrawing it from the arm.

NOTE: The spindle bearing of later model projectors is a steel bushing with ten loose bearing balls on each side of the bushing instead of a bronze sleeve bearing.

5.26.2 Install spindle and pulley in supply arm assembly with bronze sleeve bearing as follows:

- a) Insert spindle assembly in bearing, then place pulley on shaft, hub toward bearing.
- b) Insert .005-inch thickness gage between hub and bearing.
- c) Clamp the pulley and spindle together and using the hole in one side of the hub as a guide, drill (1/16") through shaft and other side of the pulley hub.
- d) Fasten pulley on shaft with the pin and remove gage.



5.26.3 Install spindle and pulley in supply arm assembly with steel bushing and bearing balls as follows:

- a) Using a small vise or similar means to hold the spindle assembly firmly in a vertical position, place washer on the shaft.
- b) Apply a light coating of Grease A&O61-3655 to the upper surface of the washer and place ten bearing balls around the shaft; the grease will retain the balls in position.
- c) Place the bushed end of the arm assembly over the end of the shaft - support the free end of the arm assembly with a block of wood of suitable height - and carefully lower the arm so that the bearing balls go into the recess.
- d) Apply a small amount of grease to the upper recess and place ten bearing balls in position.
- e) Add the other washer and place the pulley on the shaft, hub toward the washer.
- f) Insert a .005-inch thickness gage between hub and washer.
- g) Clamp the pulley and spindle together and using the hole in one side of the hub as a guide, drill (1/16") through the shaft and through the other side of the hub.
- h) Fasten pulley on shaft with the pin and remove gage.


5.27 ELEVATING MECHANISM

5.27.1 Remove

- a) Mechanism from case (Section 5.1.1).
- b) Parts from mechanism as required.

5.27.2 Install


Parts in reverse order of removal so that knob is vertical when elevation is fully retracted. Lubricate the rack teeth, pinion teeth, and both sides of the bracket with A&O61-3619 Lubricant as required.



5.28 SOLAR CELL MOUNT AND CABLE ASSEMBLY

5.28.1 Remove

- a) Sound optics by unhooking the mount spring from the exciter lamp bracket.
- b) Mechanism from case (Section 5.1.1).
- c) Flywheel (Section 5.15.1) and retaining rings from sound drum shaft so sound drum can be slide out far enough to remove the solar cell mount screw.




- d) Screw holding the cable clamp (1) and stand-off (2) in place and discard these parts, (later models do not use these parts).
- e) Rubber sleeving (3) from cable and discard, then the cable plug by desoldering, and the mount and cable assembly.

5.28.2 Install

Parts in reverse order of removal. Do not use cable clamp (1), standoff (2), or rubber sleeve (3): late style cables are shorter and have a strain relief within the mount.

5.29 LAMP SOCKET


5.29.1 Adjust




Lamp socket position by turning screw while observing projected filament image using a loupe in front of the lens; filament image should be centered.

5.30 SOUND SYSTEM (Optics and Related Area)


5.30.1 Adjust




- a) Sound optics bracket assembly (1) to center the scanning beam. Observe the beam in reference to the lower edge of sound drum and center of solar cell. The edge of the scanning beam should clear the rim of the sound drum by .012" and the light from the scanning beam should strike the solar cell in the center. Loosen lock screw (2) and locknut (3), then turn adjusting screw (4) as needed. Tighten locknut (3) and apply a small amount of air-drying cement to screw and locknut.



- b) Position of pressure roller for proper overhang of sound track beyond the sound drum. The distance between the inner surface of flange (1) on pressure roller and the flat surface of the sound drum (2) should be .030" $\pm$.005". Roller position must insure that inner raised surface of sound drum contacts the film only in area between picture and sound track. Use Buzz Track Test Film (760383) and turn hexagonal spacer to move pressure roller assembly in or out, as required, so that neither tone is heard or both tones can be heard at the same level.



- c) Sound optics bracket assembly to focus the sound optics using 5,000 cycle test film (760382). With the fidelity control lever (1) in the center of its travel, loosen the lock screw (2) and turn the eccentric (3) until the sound output is at maximum. Tighten lock screws (2 and 4) and apply a small amount of air-drying cement to them.



- d) Sound optics for azimuth alignment and for minimum microphonics. Loosen lock nut (1) and turn screw (2) to adjust sound optics for maximum response, using 5,000 cycle test film (760382). Loosen lock nut (3), turn the volume up to maximum and, while tapping the sound head casting, turn screw (4) to adjust for minimum microphonics. Tighten lock nut (3) and apply a small amount of air-drying cement to screw and nut. Repeat azimuth adjustment. Tighten lock nut (1) and apply a small amount of air-drying cement to screw and nut. Lubricate the two recesses of the sound optics with A&O61-3655 Grease.

6. AMPLIFIER SERVICING

A technical write-up giving details of the all-transistor amplifier for the Kodak Pageant Sound Projector, Model AV-126-TR, is available from Eastman Kodak Company, Apparatus Service Department, Rochester 4, New York.

6.1 PRINTED CIRCUITS - GENERAL



Servicing of printed circuit boards requires somewhat different techniques than those employed in trouble-shooting wired amplifiers. For one thing, more care is necessary in desoldering and soldering. Because excessive heat applied to a component board may cause permanent damage to it, a 30-to-50 watt, pencil-type soldering iron is recommended.

Generally, it will be found that removal of components is easier if flush cutting pliers are used to clip off the ends of the leads and some of the solder at the joint before the iron is applied to heat the joint. Hold the tip of the iron to the soldered joint only, not to the pattern near the joint. Avoid prolonged heating of the joint; remove the component as quickly as possible, using pliers, the forked end of a soldering aid, etc. Very often, the forked end of a soldering aid can be used to reach in on the underside of a printed circuit board and remove a component located in an area that might be difficult to get to with some other tool. The reamer tip can be used to open up the holes in the board for the component leads.

Although a replacement component can usually be installed on the pattern side of the board without affecting amplifier performance, the AV-126-TR amplifier is designed so that most components can be easily installed in the original position. Again, avoid prolonged heating of the "printed" pattern at the joint when installing the component.

If a "printed" conductor is cracked, a simple repair can be made by first scraping the conductor about 1/4" on either side of the break to clean the copper and then applying a small piece of bare hookup wire over the break. The wire should be tinned before placing it in position. Hold the tip of the iron on the wire just long enough to allow the applied solder to flow across the break so that the wire is imbeded.

For detailed information on design and construction and additional hints on servicing printed circuits, refer to Printed Circuit Diagnosis Made Easy (a Howard W. Sams publication), to Rider's Introduction to Printed Circuits, and other books; also, to bulletins available from the various tube manufacturers.



6.2 TRANSISTORIZED CIRCUITS - GENERAL

Basic trouble shooting of a transistorized circuit is similar to tube circuitry except that the operating voltages are generally much lower. Voltmeter checks are done in exactly the same manner but care should be used in making ohmmeter checks since component damage can result from the applied current. Although the transistor is probably the most reliable component in the circuit and should be the last component to be suspected, a transistor tester is a good investment and several good inexpensive models are available.


A certain amount of care is needed when handling a transistor; they are sensitive to heat and since the leads are generally quite small, proper orientation in the socket is important. A basic understanding of transistor operation and theory is very important to the serviceman and many sources of this information are available. Articles appear in nearly every issue of the various technical magazines and several manufacturers publish transistor manuals which contain a discussion on theory, construction, servicing, etc. More detailed information can be found in various books such as: "Basic Electronics Volume 6" (A Rider Publication), "Transistors - Theory and Practice" (a Gernsback Publication), and many others.

6.3 SERVICING THE AV-126-TR AMPLIFIER

To remove amplifier from the case see Section 5.2.

6.3.1 Power Supply

Since it is necessary to disconnect only the solar cell lead when removing the amplifier from the case, the amplifier can still be operated and tested. It may sometimes be necessary to use extension leads to allow easier accessibility to the amplifier. If a separate power supply is required, use a source of DC voltage that will supply a negative 25 to 30 volts measured across the amplifier filter capacitor C-13. Tool #1034 is available for this purpose, or one can be made as shown below, using parts from the amplifier power supply.




- 1 -#159637 TRANSFORMER
- 2 -#164193 SILICON RECTIFIER (RCA TYPE IN 3253)
200 PIV, 750 ma
- 1 -#159416 - 1500 MFD 5VDC ELECTROLYTIC CAPACITOR


6.3.2 SERVICE HINTS

- a) Although many of the components can be removed and replaced without separating the printed circuit board from the amplifier plate, these operations can be more easily performed if the amplifier is "opened-up". To do this, proceed as follows:

1. Remove the control knobs (tone control - friction fit, volume control - setscrew).



2. Unsolder the two leads of the Diode Stabistor (CR-5) that is cemented to the amplifier plate.



3. Remove the four circuit board mounting screws (arrows) and swing board over.

- b) The 500K bias control (R-28) is variable so that the exact value of correct bias may be selected for any given set of transistors. If any of the transistors are replaced, it may be necessary to adjust R-28 to obtain the proper undistorted output (Section 6.3.3a).
- c) The 25K potentiometer (R-34) is used to compensate for the slight variations in the sensitivity of different solar cells. It will require adjusting only if the solar cell, exciter lamp, or transistors Q1 or Q2 are changed. Adjust to obtain the proper undistorted output (Section 6.3.3a).
- d) When replacing either Q7 or Q8 (2N307 or T1-370 Transistor) apply a moderate amount of Transistor Z-5 Silicon Compound No.8101 (General Cement Electronics Company) to both sides of the insulating washers.



6.3.3 Specification (input voltage to amplifier, 117)

- a) Output: * 6.7 volts minimum 400 cycle test film as signal source, no visible distortion on an oscilloscope (a slight amount of "filling-in" will be visible in the lower half of the signal which does not affect the undistorted output).
- b) Sensitivity: (Tone Control full counterclockwise)
 1. Film Channel - 8 watts (* 6.9 volts) output, 1000 cycle signal of 0.66 millivolts $\pm$ 4 db applied directly to the photocell input socket.
 2. Microphone Channel - 8 watts (* 6.9 volts) output, 100 cycle signal of 22 millivolts $\pm$ 3 db applied directly to the microphone input receptacle.
 3. Phonograph Channel - 8 watts (* 6.9 volts) output, 1000 cycle signal of 220 millivolts $\pm$ 3 db applied directly to the phonograph input receptacle.
- c) Power supply
 1. DC voltage to the amplifier: 25 to 30 volts (no load), measured across the filter capacitor C-13 at line voltage.
 2. DC voltage to the exciter lamp: 4.0 $\pm$ 0.2 volts with ripple content not exceeding 150 millivolts, measured across a resistor load of 5 ohms $\pm$ 1%, 5 watts (in place of the exciter lamp) at a line voltage of 117.


* Measured across a 6 ohm, 25 watt, dummy speaker load.

7. SCHEMATIC AND WIRING DIAGRAMS

7.1 POWER SUPPLY AND MASTER CONTROL SWITCH




7.2 SWITCH AND TERMINAL CONNECTIONS




SWITCH AND TERMINAL CONNECTIONS

AV-126-TR

7.3 VOLTAGE - CHECK AND COMPONENT LOCATING DIAGRAM



VOLTAGE - CHECK AND COMPONENT LOCATING DIAGRAM



NOMENCLATURE FOR AMPLIFIER COMPONENTS

R-1	126101	470K±10% 1/2 WATT	R-22	120508	68K±10% 1/2 WATT	C-9	159410	125MFD 50V.D.C. ELEC.	CR-1	164193	750MA 200V.PIV. DIODE	
R-2	126398	47K±10% 1/2 WATT	R-23	126903	22K±10% 1/2 WATT	C-10	159413	10MFD 50V.D.C. ELEC.	CR-2	164193	750MA 200V.PIV.DIODE	
R-3	160558	3.6K±5% 1/2 WATT	R-24	159406	220ohm±10% 1/2 WATT	C-11	160673	0.68MFD±10%100V.D.C.	CR-3	164193	750MA 200V.PIV.DIODE	
R-4	126900	10K±10% 1/2 WATT	R-25	159407	47ohm±10% 2 WATT	C-12	162883	60MFD 50V.D.C. ELEC.	CR-4	164193	750MA 200V.PIV.DIODE	
R-5	136709	47ohm±10% 1/2 WATT	R-26	159633	25ohm±10% 25 WATT	C-13	159416	1500MFD 50V.D.C. ELEC.	Q-1	159424	PNP TRANSISTOR 2N109 OR 2N1370	
R-6	126398	47K±10% 1/2 WATT	R-27	159427	5K VOLUME CONTROL	C-14	159634	1300MFD 35V.D.C. ELEC.	Q-2	159424	PNP TRANSISTOR 2N109 OR 2N1370	
R-7	119816	1K±10% 1/2 WATT	R-28	159428	500K BIAS CONTROL	C-15	159634	1300MFD 35V.D.C. ELEC.	Q-3	159424	PNP TRANSISTOR 2N109 OR 2N1370	
R-8	126900	10K±10% 1/2 WATT	R-29	154866	5.6K±10% 1/2 WATT	C-16	159416	1500MFD 50V.D.C. ELEC.	Q-4	159424	PNP TRANSISTOR 2N109 OR 2N1370	
R-9	119816	1K±10% 1/2 WATT	R-30	120504	33K±10% 1/2 WATT	C-17	161022	25MFD 10V.D.C. ELEC.	Q-5	159424	PNP TRANSISTOR 2N109 OR 2N1370	
R-10	152753	7.5K±5% 1/2 WATT	R-31	160672	0.25ohm±5% 1/2 WATT	C-18	159418	100MMFD 50 V. MIN.	Q-6	159425	NPN TRANSISTOR 2N35 OR 2N1304	
R-11	126394	4.7K±10% 1/2 WATT	R-32	160672	0.25ohm±5% 1/2 WATT	C-20	161020	.005MFD 50V. MIN.	Q-7	159426	PNP TRANSISTOR 2N307 OR TI-370	
R-12	143223	150K±10% 1/2 WATT	R-33	872378	100ohm±10% 1/2 WATT	C-21	159420	.004MFD 50V. MIN.	Q-8	159426	PNP TRANSISTOR 2N307 OR TI-370	
R-13	126401	150ohm±10% 1/2 WATT	*R-34	164603	25K POT.	C-22	161021	.0018 MFD 50V. MIN.	S-1	154870	DPDT SLIDE SWITCH	
R-14	159406	220ohm±10% 1/2 WATT	C-1	161022	25MFD 10V.D.C. ELEC.	C-23	161021	.0018MFD 50V. MIN.	S-2	159435	5 POS. ROTARY-TONE CONTROL	
R-15	119816	1K±10% 1/2 WATT	C-2	161022	25MFD 10V.D.C. ELEC.	C-24	159418	100MMFD 50V. MIN.	S-3	159533	PROJ. CONTROL SWITCH	
R-16	870569	2.7K±10% 1/2 WATT	C-3	159649	.022MFD 100 V.D.C.	C-25	159409	.027MFD 100V. MIN.	S-4	159445	AMP. SWITCH & TH'D'L'T SOCKET ASS'Y	
R-17	872379	1.2K±10% 1/2 WATT	C-4	161022	25MFD 10V.D.C. ELEC.	C-26	159414	.033MFD 100V. MIN.	J-1			
R-18	154868	500ohm±10% 2 WATT W.W.	C-5	159408	75MFD 25V.D.C. ELEC.	C-27	159419	.047MFD 100V. MIN.	DS-1	PROJECTION LAMP		
R-19	153447	200ohm±5% 1/2 WATT	C-6	159408	75MFD 25V.D.C. ELEC.	C-29	159413	10MFD 50V.D.C. ELEC.	DS-2			
R-20	153447	200ohm±5% 1/2 WATT	C-7	159411	50MMFD 50V.MIN.	CR-5	159444	DIODE STABISTOR S320G	P-1	159551	POWER CORD	
R-21	120506	15K±10% 1/2 WATT	C-8	159412	60MFD 6V.D.C. ELEC.	CB-1	151383	CIRCUIT BREAKER	T-1	159637	POWER TRANSFORMER	

*ADDED BEGINNING WITH "B" SERIAL NUMBERS


AMPLIFIER SCHEMATIC CIRCUIT FOR KODAK PAGEANT SOUND PROJECTOR, MODEL AV-126-TR

NOMENCLATURE FOR AMPLIFIER COMPONENTS


R-1	126101	470K±10% 1/2 WATT
R-2	126398	47K±10% 1/2 WATT
R-3	160558	3.6K±5% 1/2 WATT
R-4	126900	10K±10% 1/2 WATT
R-5	136709	47ohm±10% 1/2 WATT
R-6	126398	47K±10% 1/2 WATT
R-7	119816	1K±10% 1/2 WATT
R-8	126900	10K±10% 1/2 WATT
R-9	119816	1K±10% 1/2 WATT
R-10	152753	7.5K±5% 1/2 WATT
R-11	126394	4.7K±10% 1/2 WATT
R-12	143223	150K±10% 1/2 WATT
R-13	126401	150ohm±10% 1/2 WATT
R-14	159406	220ohm±10% 1/2 WATT
R-15	119816	1K±10% 1/2 WATT
R-16	870569	2.7K±10% 1/2 WATT
R-17	872379	1.2K±10% 1/2 WATT
R-18	154868	500ohm±10% 2 WATT W.W.
R-19	153447	200ohm±5% 1/2 WATT
R-20	153447	200ohm±5% 1/2 WATT
R-21	120506	15K±10% 1/2 WATT
R-22	120508	68K±10% 1/2 WATT
R-23	126903	22K±10% 1/2 WATT
R-24	159406	220ohm±10% 1/2 WATT
R-25	159407	47ohm±10% 2 WATT
R-26	159633	25ohm±10% 25 WATT
R-27	159427	5K VOLUME CONTROL
R-28	159428	500K BIAS CONTROL
R-29	154866	5.6K±10% 1/2 WATT
R-30	120504	33K±10% 1/2 WATT
R-31	160672	0.25ohm±5% 1/2 WATT
R-32	160672	0.25ohm±5% 1/2 WATT
R-33	872378	100ohm±10% 1/2 WATT
* R-34	164603	25K POT.
C-1	161022	25MFD 10V.D.C. ELEC.
C-2	161022	25MFD 10V.D.C. ELEC.
C-3	159649	.022MFD 100 V.D.C.
C-4	161022	25MFD 10V.D.C. ELEC.
C-5	159408	75MFD 25V.D.C. ELEC.
C-6	159408	75MFD 25V.D.C. ELEC.
C-7	159411	50MMFD 50V. MIN.
C-8	159412	60MFD 6V.D.C. ELEC.
C-9	159410	125MFD 50V.D.C. ELEC.
C-10	159413	10MFD 50V.D.C. ELEC.
C-11	160673	0.68MFD±10%100V.D.C.
C-12	162883	60MFD 50V.D.C. ELEC.
C-13	159416	1500MFD 50V.D.C. ELEC.
C-14	159634	1300MFD 35V.D.C. ELEC.
C-15	159634	1300MFD 35V.D.C. ELEC.
C-16	159416	1500MFD 50V.D.C. ELEC.
C-17	161022	25MFD 10V.D.C. ELEC.
C-18	159418	100MMFD 50 V. MIN.
C-20	161020	.005MFD 50V. MIN.
C-21	159420	.004MFD 50V. MIN.
C-22	161021	.0018MFD 50V. MIN.
C-23	161021	.0018MFD 50V. MIN.
C-24	159418	100MMFD 50V. MIN.
C-25	159409	.027MFD 100V. MIN.
C-26	159414	.033MFD 100V. MIN.
C-27	159419	.047MFD 100V. MIN.
C-29	159413	10MFD 50V.D.C. ELEC.
CR-5	159444	DIODE STABISTOR S320G
CB-1	151383	CIRCUIT BREAKER
CR-1	164193	750MA 200V.PIV. DIODE
CR-2	164193	750MA 200V.PIV. DIODE
CR-3	164193	750MA 200V.PIV. DIODE
CR-4	164193	750MA 200V.PIV. DIODE
Q-1	159424	PNP TRANSISTOR 2N109 OR 2N1370
Q-2	159424	PNP TRANSISTOR 2N109 OR 2N1370
Q-3	159424	PNP TRANSISTOR 2N109 OR 2N1370
Q-4	159424	PNP TRANSISTOR 2N109 OR 2N1370
Q-5	159424	PNP TRANSISTOR 2N109 OR 2N1370
Q-6	159425	NPN TRANSISTOR 2N35 OR 2N1304
Q-7	159426	PNP TRANSISTOR 2N307 OR TI-370
Q-8	159426	PNP TRANSISTOR 2N307 OR TI-370
S-1	154870	DPDT SLIDE SWITCH
S-2	159435	5 POS. ROTARY-TONE CONTR
S-3	159533	PROJ. CONTROL SWITCH
S-4	159445	AMP. SWITCH & TH'D'L'T SOCKET ASS'Y
J-1		PROJECTION LAMP
DS-1		EXCITER LAMP
DS-2		POWER CORD
P-1	159551	POWER TRANSFORMER
T-1	159637	POWER TRANSFORMER

* ADDED BEGINNING WITH "B" SERIAL NUMBERS

WHITE TO MASTER CONTROL SWITCH
GREEN TO GROUND CONNECTION
BLACK TO MASTER CONTROL SWITCH
RED TO MASTER CONTROL SWITCH



7.6 COMPONENT BOARD



COMPONENT BOARD

Parts List

Corrected to MARCH 1963

KODAK PAGEANT SOUND PROJECTOR

Model AV-256-TR

BEGINNING WITH SERIAL No. 256-B01001






FIGURE 1




FIGURE 2 CASE BOTTOM




FIGURE 3 CASE BACK




FIGURE 4




FIGURE 5




FIGURE 6 EXCITER LAMP COVER ASSEMBLY-160707




FIGURE 7

SUPPLY ARM ASSEMBLY-160722
See Figure 9




FIGURE 8 SUPPLY ARM ASSEMBLY
AND RELATED PARTS

PULLEY
1 1/8 OD-167289
1 1/4 OD-167290




FIGURE 9 SUPPLY ARM ASSEMBLY-160722




FIGURE 10 SPINDLE ASSEMBLY-165173




FIGURE 11 TAKE-UP ARM AND RELATED PARTS




FIGURE 12




FIGURE 13




FIGURE 15




FIGURE 14 TAKE-UP SPINDLE ASSEMBLY-160716




FIGURE 16




FIGURE 17




FIGURE 18




FIGURE 19 AMPLIFIER AND EXCITER LAMP
POWER SUPPLY ASSEMBLY-161845
See Figure 20




FIGURE 21




FIGURE 20 AMPLIFIER AND EXCITER LAMP
POWER SUPPLY ASSEMBLY-161845




FIGURE 22




FIGURE 23 CONDENSER MOUNT ASSEMBLY-121510




FIGURE 24




FIGURE 25




FIGURE 26

ARM AND PULLEY ASSEMBLY-160718
See Figure 28




FIGURE 27

SHUTTER DRIVE ARM AND
SHAFT ASSEMBLY-166261




FIGURE 28 ARM AND PULLEY ASSEMBLY-160718

SEE FIGURES 30 THRU 35




FIGURE 29 CONTROL BRACKET AND RELATED PARTS




FIGURE 30 TYPE I




FIGURE 31 TYPE II




FIGURE 32 TYPE III




FIGURE 33 TYPE IV




FIGURE 34




FIGURE 35 KIT NO. K-1655-SHUTTER DRIVE BELT AND SHIFTING ROLLER KIT




FIGURE 36




FIGURE 37




FIGURE 38




FIGURE 39




FIGURE 40




FIGURE 41




FIGURE 42




FIGURE 43




FIGURE 44




FIGURE 45




FIGURE 46 SOUND HEAD BRACKET ASSEMBLY-160392
(Includes bearing, shaft, and stud)




FIGURE 47




FIGURE 48




FIGURE 49




FIGURE 50 SHUTTER ASSEMBLY-134124
See Figure 51




FIGURE 51

AVAILABLE ONLY IN ASSEMBLY-134124





FIGURE 52



*For Early Model Projectors

FIGURE 53




FIGURE 54







FIGURE 57 UPPER SPROCKET PLATE ASSEMBLY-160720






FIGURE 59




FIGURE 60 LOWER SPROCKET PLATE ASSEMBLY-160719




FIGURE 61




FIGURE 62




FIGURE 63 APERTURE PLATE AND PAD ASSEMBLY-166488

Available only in
Assembly-166488




FIGURE 64 PRESSURE PAD ASSEMBLY-166488

Available only in
Assembly-138144




FIGURE 65 APERTURE PLATE ASSEMBLY-138144




FIGURE 66




FIGURE 67




FIGURE 68




FIGURE 69

MECHANISM HOUSING ASSEMBLY-159638
(Includes bearings, pin and retainer)




FIGURE 70

SEE FIGURE 73




FIGURE 72 CASE ASSEMBLY-161911

SEE FIGURES 73 AND 74




FIGURE 71 CASE ASSEMBLY-161911
See Figure 72




FIGURE 73




FIGURE 74




FIGURE 75





FIGURE 76

IMPORTANT

Cable shield must always be connected to speaker terminal No. 1. The location of the No. 1 and No. 2 speaker terminals may be reversed from those shown.



HOW TO DETERMINE NO. 1 SPEAKER TERMINAL

If the cone moves forward when a flashlight cell is placed across the speaker terminals, the terminal connected to the positive pole of the cell is the No. 1 speaker terminal.

FIGURE 77 SPEAKER WIRING DIAGRAM (October 1962)




FIGURE 78




FIGURE 79. AMPLIFIER ASSEMBLY-161842
 See Figures 80, 81, and 82





FIGURE 80


FIGURE 81

Always give PART NUMBER and NAME when ordering parts



COMPONENT BOARD ASSEMBLY-161841

FIGURE 82







FIGURE 83


WIRING DIAGRAM FOR AMPLIFIER AND EXCITER LAMP
POWER SUPPLY ASSEMBLY -161845 (January 1963)




SWITCH AND TERMINAL CONNECTIONS

FIGURE 84

-
- tor - Made to Kodak
 ics
 tor - Made to Kodak
 ics
 - Circuit, 1.125 amp
 ing, 2.0 amp break
 s - PNP, 2N1136A
 - W.W., 1 Ω 5%, 2 W
 ometer - Linear taper,
 30%, Stackpole Carbon No.
 equiv
 - W.W., 500 Ω 10%, 2 W
 - Input selector
 er Switch and Thread Lamp
 t Assembly
- C-13
 RED
 BLACK
 C-15
 BLACK
 RED
 Q7
 R-28
 Q6
 YELLOW
 WHITE
 BLUE
 PURPLE
 ORANGE
 J
 K
 L
 M
 N
 O
 P
 PHOTOCELL
 R-41
 BLACK
 SHIELD
 SHIELD TO 'P'
 BLACK TO 'O'
 GREEN
 WHITE
 S-4
 J-1
 RED
 BLACK
 R-42
 SPEAKER
 PHONO
 MIC
 BARE
 YELLOW
 BLUE
 PURPLE
 SLATE
 RED
 GREEN
 BROWN
 EK12
 CB-1
 ORANGE TO POWER SUPPLY
- AMPLIFIER WIRING DIAGRAM FOR PAGEANT SOUND PROJECTOR, MODEL AV-256-TR





MEASURE DC VOLTAGES WITH HIGH IMPEDANCE VOLTMETER WITH NO INPUT SIGNAL, AND NO EXTERNAL LOAD Numbers in circles refer to voltage check points

R-1	126101	470 K 1/2 WATT ±10%	*R-25	161829	BIAS CONTROL 50Ω ±20%	C-8	159413	10 MFD 50 VDC ELECTROLYTIC	CR-1	164193	750 MA 200 PIV DIODE
R-2	78671	47 K 1/2 WATT ±10%	R-26	147756	1.8 K 1/2 WATT ±10%	C-9	159410	125 MFD 50 VDC ELECTROLYTIC	CR-2	164193	750 MA 200 PIV DIODE
R-3	147756	1.8 K 1/2 WATT ±10%	R-27	159427	VOLUME CONTROL 5K ±30%	C-10	165556	25 MFD 50 VDC ELECTROLYTIC	CR-3	164193	750 MA 200 PIV DIODE
R-4	126900	10 K 1/2 WATT ±10%	R-28	161830	1Ω 2 WATT ±5% WIREWOUND	C-11	161831	75 MFD 6 VDC ELECTROLYTIC	CR-4	164193	750 MA 200 PIV DIODE
R-5	136709	47Ω 1/2 WATT ±10%	R-29	161830	1Ω 2 WATT ±5% WIREWOUND	C-12	159410	125 MFD 50 VDC ELECTROLYTIC	Q-1	166893	TRANSISTOR 2N217 OR 2N408 OR 2N1370
R-6	78671	47 K 1/2 WATT ±10%	R-30	159633	25Ω 25 WATT ±10% W W	*C-13	161832	1500 MFD 70 VDC ELECTROLYTIC	Q-2	166893	TRANSISTOR 2N217 OR 2N408 OR 2N1370
R-7	119816	1K 1/2 WATT ±10%	R-31	126394	4.7 K 1/2 WATT ±10%	C-14	143229	.0015 MFD ±10% 50VDC MIN. CERAMIC	Q-3	166893	TRANSISTOR 2N217 OR 2N408 OR 2N1370
R-8	126900	10K 1/2 WATT ±10%	R-32	78671	47K 1/2 WATT ±10%	*C-15	159416	1500MFD 50VDC ELECTROLYTIC	Q-4	162893	TRANSISTOR 2N1038 PNP
R-9	162891	27Ω 1/2 WATT ±5%	R-33	147756	1.8 K 1/2 WATT ±10%	C-16	161022	25 MFD 10VDC ELECTROLYTIC	Q-5	161849	TRANSISTOR 2N1136 PNP
R-10	154866	5.6 K 1/2 WATT ±10%	R-34	872378	100 Ω 1/2 WATT ±10%	C-17	161022	25 MFD 10VDC ELECTROLYTIC	Q-6	161835	TRANSISTOR 2N1136A PNP
R-11	162892	33Ω 1/2 WATT ±5%	R-35	161828	18Ω 1/2 WATT ±10%	C-18	159634	1300 MFD 35VDC ELECTROLYTIC	Q-7	161835	TRANSISTOR 2N1136A PNP
R-12	161824	51K 1/2 WATT ±5%	R-36	126901	6.8 K 1/2 WATT ±10%	C-19	159634	1300 MFD 35VDC ELECTROLYTIC	DS-1		PROJECTION LAMP
R-13	160123	680Ω 1/2 WATT ±5%	R-37	872443	12 K 1/2 WATT ±10%	C-20	161020	.005 MFD 50VDC MIN. CERAMIC	DS-2	120359	PHOTOCELL EXCITER LAMP
R-14	123301	1.1K 1/2 WATT ±5%	R-38	112546	2.7 K 1/2 WATT ±10%	C-21	159420	.004 MFD 50VDC MIN. CERAMIC	*S-1	154870	INPUT SELECTOR SWITCH
R-15	126905	27 K 1/2 WATT ±10%	R-39	154868	500Ω 2 WATT ±10% W W	C-22	161021	.0018 MFD 50 VDC MIN. CERAMIC	*S-2	159435	TONE CONTROL SWITCH
R-16	866521	390Ω 1/2 WATT ±10%	*R-40	161857	CONTROL-FREQUENCY RESPONSE 2.5K	C-23	161021	.0018 MFD 50 VDC MIN. CERAMIC	*S-3	159533	PROJECTOR CONTROL SWITCH
R-17	872379	1.2 K 1/2 WATT ±10%				C-24	159418	100 MMFD 50 VDC MIN. CERAMIC	*S-4		AMPLIFIER CONTROL SWITCH
R-18	165557	600 Ω 5 WATTS ±5% W W				C-25	159409	.027 MFD 100 VDC MIN. MYLAR	*J-1	159445	THREADLAMP SOCKET
R-19	161827	91Ω 1 WATT ±5%	C-1	161022	25 MFD 10 VDC ELECTROLYTIC	C-26	159414	.033 MFD 100 VDC MIN. MYLAR	CB-1	151383	CIRCUIT BREAKER
R-20	127852	300 Ω 5 WATT ±10% W W	C-2	161022	25 MFD 10 VDC ELECTROLYTIC	C-27	159419	.047 MFD 100 VDC MIN. MYLAR	*T-1	161836	DRIVER TRANSFORMER
R-21	872443	12 K 1/2 WATT ±10%	C-3	161858	.015 MFD 50 VDC MYLAR	C-28	164758	40 MFD 25 VDC ELECTROLYTIC	*T-2	161837	POWER TRANSFORMER
R-22	126900	10 K 1/2 WATT ±10%	C-4	161022	25 MFD 10 VDC ELECTROLYTIC	C-29	159413	10 MFD 50 VDC ELECTROLYTIC	P-1	159551	POWER CORD
R-23	161828	18 Ω 1/2 WATT ±10%	C-5	164758	40 MFD 25 VDC ELECTROLYTIC	C-30	164757	.001 MFD ±10% 50 VDC MIN. CERAMIC	R-41	164603	25 K POTENTIOMETER
R-24	126900	10 K 1/2 WATT ±10%	C-6	161022	25 MFD 10 VDC ELECTROLYTIC	C-31	164757	.001 MFD ±10% 50 VDC MIN. CERAMIC	R-42	154868	500Ω 2 WATTS ±10% W W

*Use exact replacement - made to Kodak specifications

AMPLIFIER SCHEMATIC CIRCUIT (January 1963)

PART NO.	PART NAME	FIG.	PART NO.	PART NAME	FIG.
K-1655	*Photocell Exciter Lamp, ASA Code BSK, 6 V, 1 amp . .	7,87	78624	Washer.	51
	*Lamp, ASA Code DDB, 750 W, 115-120 V	22,87	78671	Resistor - 47 K Ω 10%, 1/2 W .	82,87
	*Lamp, ASA Code DFD, 1000 W, 115-120 V	22,87	79097	Washer.	53
	*Lamp, ASA Code DHT, 1200 W, 115-120 V	22,87	80753	Lockwasher - Int tooth, 3/8 . .	79
	*KODAK Projection EKTANAR Lens, 2-inch, f/1.6.	1	80969	Washer.	12
	*KODAK Projection EKTANON Lens, 1 1/2-inch, f/2.0.	1	83373	Reflector	22
	*KODAK Projection EKTANON Lens, 3-inch, f/2.0.	1	86892	Washer.	42
	*KODAK Projection EKTANON Lens, 4-inch, f/2.5.	1	87269	Washer.	30
	Shutter Drive Belt and Shifting Roller Kit	35	87777	Screw	47
	7514 Ball - Carbon steel, 3/16. . . .	54	88937	Plate	74
	12177 Ball - Carbon steel, 1/8	54	89342	Lockwasher - Ext tooth, No. 8	20
	13775 Lens - Condenser rear	23	90630	Washer - 3/32 ID x 1/4 OD x .020 thk	61
	25739 Washer.	16	92950	Washer - .005	51
	25883 Ball - Carbon steel, 3/32. . . .	9	93847	Washer.	28
	33992 Lockwasher - Int tooth, No. 10.	29	97826	Ring - Retaining, ext, Truarc No. 5100-25 or equiv.	69
	37266 Washer - 5/32 ID x 3/8 OD x .049 thk.	80	101470	Screw - Mach, min hd, 4-40 x 1/4.	53
	37492 Nut - Hex, 5/16-24.	12	107101	Setscrew - Hex sock., cone pt, 5-40 x 3/16	59,66,69
	42533 Nut - Hex, 6-32	73,80	107243	Screw - Mach, flat hd, 4-40 x 3/16	21
	42745 Nut - Hex, 10-32	80	107606	Ring - Retaining, ext, Truarc No. 5100-31 or equiv.	28
	42874 Lockwasher - Int tooth, No. 6	27,38	108546	Nut - 10-32, Elastic Stop Nut No. 22TM-02 or equiv . .	16
	43609 Nut - Hex, 8-32	20	109571	Setscrew - Hex sock., cone pt, 4-40 x 1/8	39
	45322 Nut - Hex, 4-40	42,44	112546	Resistor - 2700 Ω 10%, 1/2 W.	82,87
	46236 Washer.	12	116264	Rivet	6
	46893 Lockwasher - Int tooth, 5/16 .	12	117165	Spring - Condenser lens separator	23
	48023 Washer.	13	117543	Plate - Claw pivot	55
	48969 Washer - .010	51	117547	Eccentric - Stroke adjusting. .	55
	50088 Setscrew - Hex sock., cup pt, 1/4-20 x 3/4	15	117548	Pivot - Framing lever.	53
	53768 Setscrew - Hex sock., cup pt, 8-32 x 1/4.	21,25	117549	Spacer - Claw pivot plate. . .	55
	55776 Lockwasher - Int tooth, No. 6	15	117705	Cam - Pulldown.	51
	56786 Washer - 13/32 ID x 13/16 OD x .065 thk.	2	117713	Cup - Damping bearing	61
	57155 Nut - Hex, 4-40	48	117725	Worm - Shutter shaft	69
	58694 Plunger	10,14	117736	Sound Optics Assembly	44
	58696 Spring	10,14	117762	Spring - Sprocket roller	58,60
	69682 Lockwasher - Int tooth, No. 6	73	119395	Washer.	37
	71638 Clamp	48	119816	Resistor - 1000 Ω 10%, 1/2 W.	82,87
	74906 Washer.	67	120213	Sleeve - Mechanism support bracket.	18
	75847 Washer - 1/4 ID x 9/16 OD x .065 thk	2	120243	Shaft - Rewind shift plate. . .	67
	76529 Screw - Cap, hex sock, hd, 10-32 x 3/8	29	120335	Washer.	47
	77219 Washer.	9	120389	Rivet	65
	78621 Lockwasher - Ext tooth, No. 10.	80	120391	Guide - Aperture plate	65
			120392	Spring - Side guide.	65
			120393	Rivet	65,68
			120422	Washer.	18,49
			120438	Link - Pressure roller equalizing	40
			120444	Grommet	7,11,18,21
			120445	Sleeve	7,11,21 25,70

*Listed in Kodak Price Catalog

PART NO.	PART NAME	FIG.	PART NO.	PART NAME	FIG.
120456	Bearing - Ball, Norma Hoffman No. R-4-PP oil lub, or equiv	39	123851	Belt - Rewind	1,7
120466	Spring - Sound optics bracket .	41	123856	Washer.	8
120468	Eccentric - Sound optics bracket.	42	123857	Washer - Spring, Shakeproof No. 3502-20-7 or equiv	8
120471	Post - Sound optics mount adjusting.	44	123869	Support - Lower loop	56
120475	Spring - Sound optics mount. .	44	123885	Spring - Rewind shaft lever detent.	68
120476	Nut	44	123898	Spacer - Fan housing	15
120486	Spring - Sprocket guard detent.	60	123970	Screw - Mach, pan hd, 6-32 x 1 3/4.	15
120642	Washer.	41,58,60	124128	Lockwasher - Int tooth, alternate twist, 3/8, Shakeproof No. 1220-05 or equiv	8
120672	Clip - Reel spindle.	10,14	124214	Washer - Spring, Shakeproof No. 3502-10-28 or equiv. . . .	16
120674	Bearing - Ball, Norma Hoffman No. R-4-PP grease lub, or equiv	69	124338	Screw - Tap., Type F, pan hd, 10-32 x 3/8.	79
120986	Washer.	39	124404	Sleeve	2
121507	Sprocket Roller Plate Assembly	58,60	124606	Damping Arm Assembly	61
121510	Condenser Mount Assembly . .	22,23	124832	Screw - Mach, min hd, 2-56 x 3/16	45,57,59
121517	Arm Assembly.	40	125104	Spring - Claw	54
122233	Washer.	8	125349	Washer.	6,72
122608	Bracket - Speaker cable	76	125789	Ball - Nylon, 3/16	58,60,70
122666	Screw - Mach, pan hd, 4-40 x 3/8.	42	125854	Grommet	2
122686	Screw - Wood, rd hd, No. 8 x 1/2	76	126101	Resistor - 470 K Ω 10%, 1/2 W.	82,87
122713	Screw - Mach, pan hd, 6-32 x 1/2.	1,17,57	126200	Roller	31,32,35
122714	Screw - Mach, pan hd, 8-32 x 1/2.	1	126284	Pawl	13
122717	Screw - Mach, pan hd, 4-40 x 3/16	5,21,22, 41,56,70	126319	Gear - Reverse drive differential	66
122720	Screw - Mach, pan hd, 4-40 x 5/16	42	126321	Gear and Sprocket Drive Assembly	66
122721	Screw - Mach, pan hd, 6-32 x 5/16	57,59,67	126326	Pulley - Rewind drive.	67
122727	Screw - Mach, pan hd, 10-32 x 1/2	80	126332	Chain - Reverse flywheel drive	15,39
122730	Screw - Mach, pan hd, 4-40 x 5/8.	43,48	126355	Screw - Mach, pan hd, 6-32 x 1 5/8.	80
122767	Screw - Mach, pan hd, 10-32 x 1.	2	126394	Resistor - 4700 Ω 10%, 1/2 W.	82,87
122778	Screw - Mach, pan hd, 6-32 x 1	5	126751	Plate - Sprocket.	57,59
122791	Screw - Tap., Type A, pan hd, No. 10 x 3/4	2,71,76	126752	Sprocket.	57,59
122808	Screw - Mach, pan hd, 4-40 x 1/8.	56	126841	Collar	57
122814	Screw - Mach, pan hd, 2-56 x 3/16	44,61	126842	Stud.	67
122992	Nut - Hex, 6-32	27,38	126900	Resistor - 10 K Ω 10%, 1/2 W .	82,87
123153	Setscrew - Hex sock., cup pt, 5-40 x 3/16	1	126901	Resistor - 6800 Ω 10%, 1/2 W .	82,87
123301	Resistor - 1100 Ω 5%, 1/2 W. .	82,87	126905	Resistor - 27 K Ω 10%, 1/2 W .	82,87
123363	Washer.	16	127184	Stud - Sprocket drive	57
123633	Screw - Tap., Type B, pan hd, No. 2 x 1/8	6	127852	Resistor - W.W., 300 Ω 10%, 5 W	82,87
123639	Spring - Handle	74	127868	Spring - Pulldown in-and-out .	52
			128527	Ring - Retaining, ext, Truarc No. 5133-18 or equiv.	49,53
			128713	Washer.	51
			128838	Foot.	2,71
			128967	Rivet	71
			129404	Roller - Pressure	40
			129413	Spring - Pressure pad.	64
			129414	Post - Pressure pad hinge. . .	63
			129415	Spring - Gate mounting	63
			129457	Spring - Lens retaining.	70
			129458	Catch - Film gate.	70

Always give PART NUMBER and NAME when ordering parts

PART NO.	PART NAME	FIG.	PART NO.	PART NAME	FIG.
129461	Spring - Loop restorer	41	140110	Washer.	13
129464	Pivot - Loop restorer	41	140111	Washer.	25
129465	Handle - Loop restorer	40	140118	Window.	6
129467	Anchor - Loop restorer spring.	41	141285	Pin - Spring, stain. steel, 3/32 x 1/4.	10,14
129672	Pin - Dowel, 1/8 x 5/8	13	141537	Setscrew - Hex sock., cup pt, 4-40 x 1/4.	36
129757	Ring - Retaining, ext, Truarc No. 5133-9 or equiv.	68	142849	Washer - Spring, Shakeproof No. 3509-08-00 or equiv.	47
129870	Screw - Mach, pan hd, 2-56 x 5/64	64	142850	Screw.	7,56
130179	Loop Former Arm and Shaft Assembly.	41	143177	Pivot - Supply arm.	8
130340	Pin - Spring, 1/16 x 3/8	9	143179	Screw.	4
130432	Washer.	30,31, 32,35	143206	Fan	26
130610	Clip.	25	143229	Capacitor - Ceramic disk, 1500 MMFD 10%, 450 VDC	81,87
131075	Ring - Retaining, ext, Truarc No. 5133-12 or equiv.	30,31,32, 33,35	144638	Ring - Retaining, ext, Truarc No. 5133-15 or equiv.	53
131241	Plate	75	145169	Support and Lamp Chimney Assembly	22
131263	Washer - Spring, phos bronze, Shakeproof No. 3502-20-08 or equiv.	75	145170	Socket - Lamp, made to Kodak specifications.	48
131268	Washer.	75	145264	Claw Assembly	54
131270	Setscrew - Hex sock., cone pt, 6-32 x 1/4	78	146461	Stop - Framing lever	53
131363	Spring - Reverse drive	66	146581	Washer.	31,32, 33,35
131369	Actuator - Reverse take-up clutch	66	147657	Speaker Cable and Plug Assembly	76
131544	Spring - Damping roller	61	147688	Nut - Finished hex, 1/4-28, left-hand	51
131545	Setscrew - Hex sock., oval pt, 4-40 x 5/8	44	147693	Roller - Sprocket.	58,60
131546	Spring - Pressure roller.	40	147697	Roller - Loop restorer	40
131563	Clutch and Bushing Assembly.	49	147756	Resistor - 1800 Ω 10%, 1/2 W.	82,87
131564	Bracket and Stud Assembly	49	147781	Screw - Mach, pan hd, 8-32 x 5/8.	25
132036	Bracket Assembly	44	147832	Socket - Switchcraft Littell Jax No. S-11 or equiv	79
132053	Spring - Shutter weight return.	51	148960	Roller - Damping.	61
132172	Shutter Blade and Studs Assembly (Inner)	51	149578	Cam - In-and-out.	51
132173	Shutter Blade and Studs Assembly (Outer)	51	149738	Washer.	67
134124	Shutter Assembly.	50,51	150124	Fastener - Sems, mach, pan hd, 4-40 x 3/16.	40,52,61
134125	Shutter Weight Assembly.	51	150125	Fastener - Sems, mach, pan hd, 4-40 x 5/16.	39,53,55
136709	Resistor - 47 Ω 10%, 1/2 W	82,87	150266	Medallion - Kodak	71
137362	Ring - Retaining, ext, Truarc No. 5133-12 or equiv.	58,60	151383	Breaker - Circuit, 1.125 amp operating, 2.0 amp break	79,85,87
137413	Rivet	79	151409	Shaft - Shutter.	69
138142	Baffle.	63	151951	Fastener - Sems, mach, pan hd, 6-32 x 3/16.	52,54,68
138144	Aperture Plate Assembly.	63,65	151952	Fastener - Sems, mach, pan hd, 6-32 x 3/8.	19,29
138147	Stop - Sound drum shaft.	72	152627	Screw - Tap., Type F, pan hd, 4-40 x 3/16.	81
138229	Washer.	3	153360	Roller	31,32, 33,35
138232	Washer.	76	153930	Adapter - Grounding, Royal Electric No. 210 or equiv.	1
138252	Ring - Retaining, ext, Truarc No. 5103-25 or equiv.	39	154621	Washer.	78
138254	Ring - Retaining, ext, Truarc No. X5133-31 or equiv.	75	154866	Resistor - 5600 Ω 10%, 1/2 W.	82,87
138688	Grommet	7,25,70			
139480	Pad - Claw pivot, large.	54			
139481	Pad - Claw pivot, small.	54			
140102	Washer.	28			

PART NO.	PART NAME	FIG.	PART NO.	PART NAME	FIG.
154868	Resistor - W.W., 500 Ω 10%, 2 W	20,80,83, 85,87	159430	Connector - Microphone, Switchcraft No. 2501 MPC or equiv	79
154870	Switch - Made to Kodak specifications.	79,87	159431	Washer - Shoulder, Switch- craft No. S-1564 or equiv. . . .	79
155047	Screw - Mach, oval hd, 6-32 x 5/8.	72,75	159432	Washer - 1/4 ID x 1/2 OD x 1/16 thk, H. H. Smith No. 2165 or equiv	79
155055	Bracket - Elevator.	75	159433	Washer - Shoulder, Switch- craft No. 5-1078 or equiv. . . .	79
155056	Plate - Elevator spacer. . . .	75	159434	Washer - 3/8 ID x 5/8 OD x 1/16 thk, H. H. Smith No. 2168 or equiv.	79
155058	Rack	75	159435	Switch - Made to Kodak specifications.	82,87
155065	Bearing	75	159441	Screw - Mach, min hd, 6-32 x 1 3/8.	80
155229	Washer.	2,71	159442	Motor and Bracket Assembly .	26
155270	Flywheel Assembly.	16	159443	Guide.	79
155274	Hub	57	159445	Amplifier Switch and Thread Lamp Socket Assembly	79,85,87
155278	Flywheel Shaft and Sound Drum Assembly	39	159465	Fastener - Sems, mach, pan hd, 8-32 x 1	16
155282	Ratchet.	39	159511	Handle	73,74
155285	Spacer	16	159512	Grille.	71
155590	Braking Spring and Button Assembly.	40	159513	Bracket - Handle	73
155815	Hub	59	159514	Washer - Finishing, brass, National Lock No. 61-3206 or equiv	72
156258	Bearing	46	159515	Screw - Mach oval hd, 6-32 x 3/4.	72
156850	Nut - Keps lock, 10-32, Shakeproof No. 510-101810-51 or equiv	37	159516	Lock - Eagle Lock No. 05918F or equiv	71
157636	Cover.	43,75	159520	Post - Case handle.	73
157866	Fastener - Sems, mach, pan hd, 2-56 x 3/16.	63	159521	Post - Cover handle	74
158002	Setscrew - Hex sock., cup pt, 4-40 x 3/32	57	159522	Pin - Handle	73,74
158638	Spring - Condenser lens	23	159523	Plate - Handle post.	73,74
150409	Capacitor - Mylar dielectric, .027 MFD, 100 VDC.	81,87	159529	Spring - Toggle	38
159410	Capacitor - Electrolytic, 125 MFD +100% -10%, 50 VDC, I.E.I. No. APD137 or equiv	81,87	159530	Bracket	38
159413	Capacitor - Electrolytic, 10 MFD +100% -10%, 50 VDC, I.E.I. No. APD057 or equiv	81,87	159531	Arm - Toggle plate.	38
159414	Capacitor - Mylar dielectric, .033 MFD, 100 VDC.	81,87	159532	Plate	38
159416	Capacitor - Made to Kodak specifications.	80,85,87	159533	Switch - Control, made to Kodak specifications	36,87
159418	Capacitor - Ceramic disk, 100 MMFD 10%, 50 VDC. . . .	81,87	159534	Control Switch Cam and Pinion Assembly.	36
159419	Capacitor - Mylar dielectric, .047 MFD, 100 VDC.	81,87	159536	Link.	38
159420	Capacitor - Ceramic disk, .004 MFD 10%, 50 VDC	81,87	159539	Stud.	27
159422	Socket - Cinch No. 133-92-10- 034 or equiv.	79,81	159542	Housing - Fan	21
159423	Washer - Mica, .002 thk, Reliance Mica No. 734 or equiv.	79	159547	Yoke	37
159427	Potentiometer - Volume control, 5 K Ω 30%, Stackpole Carbon No. LH61 or equiv . .	82,87	159548	Screw.	37
159429	Socket - Switchcraft No. 3501FP or equiv.	79	159549	Plate	38
			159551	Cord - Power	1,87
			159552	Motor Pulley Assembly.	25
			159554	Stud - Toggle plate.	38
			159556	Pivot - Shutter drive arm . . .	27
			159557	Plate	21
			159559	Roller - Speed shifting eccentric.	30
			159560	Plate - Supply arm.	8
			159562	Spring - Shifting roller	30,31, 32,35

PART NO.	PART NAME	FIG.	PART NO.	PART NAME	FIG.
159563	Spring - Belt shifting	30,31, 32,33	160715	Pulley and Ratchet Assembly .	13
159571	Idler	67	160716	Take-up Spindle Assembly . . .	13,14
159574	Lever - Framing	53	160718	Arm and Pulley Assembly . . .	27,28,35
159576	Shaft - Take-up belt idler . . .	67	160719	Lower Sprocket Plate Assembly	59,60
159577	Ring - Retaining, ext, beryllium copper, Truarc No. 5100-21 or equiv.	13,67	160720	Upper Sprocket Plate Assembly	57
159579	Fastener - Sems, mach, pan hd, 6-32 x 1/4.	38,49	160722	Supply Arm Assembly	8,9
159580	Link - Rewind	68	160723	Elevating Knob Assembly. . . .	75
159581	Lever - Rewind	68	160724	Switch Bracket Assembly. . . .	36,37,38
159582	Shaft - Rewind lever.	68	160725	Knob Assembly	78
159583	Spacer - Upper sprocket plate.	57	160726	Belt Shifting Lever Assembly .	33,34
159584	Knob - Threading.	69	160761	Sprocket and Pawl Assembly .	39
159587	Roller	6,62	1601020	Capacitor - Ceramic disk, .005 MFD 10%, 50 VDC	81,87
159588	Shaft - Film guide roller. . . .	6	161021	Capacitor - Ceramic disk, .0018 MFD 10%, 50 VDC. . . .	81,87
159591	Shutter Drive Pulley Assembly	28	161022	Capacitor - Electrolytic, 25 MFD +100% -10%, 10 VDC, I.E.I. No. APD023 or equiv	81,87
159595	Support - Upper loop.	56	161589	Grille.	72
159605	Arm - Idler roller bearing. . .	62	161749	Shaft - Idler roller.	62
159607	Pin - Idler arm pivot	62	161752	Washer.	12
159610	Spring - Sprocket drive.	57	161755	Washer.	28
159611	Spring - Upper sprocket guard detent.	58	161756	Washer.	28
159633	Resistor - W.W., 25 Ω 10%, 25 W.	20,83,87	161793	Pivot - Take-up reel arm . . .	12
159634	Capacitor - Electrolytic, 1300 MFD, 35 VDC	19,83,87	161810	Rewind Plate and Guide Assembly	67,68
159638	Mechanism Housing Assembly	70	161824	Resistor - 51 K Ω 5%, 1/2 W . .	82,87
159644	Take-up Arm, Pin, and Bearing Assembly.	13	161827	Resistor - 91 Ω 5%, 1 W.	82,87
159657	Belt - Motor drive pulley. . . .	24	161828	Resistor - 18 Ω 10%, 1/2 W . .	82,87
159658	Plate - Take-up arm.	12	161829	Potentiometer - Bias control, made to Kodak specifications .	82,87
159659	Top - Lamp house	4	161830	Resistor - W.W., 1 Ω 5%, 2 W.	80,82, 85,87
159667	Plate - Take-up reel arm tension adjusting.	12	161831	Capacitor - Electrolytic, 75 MFD, 6 VDC	81,87
159670	Spacer	4	161832	Capacitor - Made to Kodak specifications.	80,85,87
159671	Screw - Tap., Type A, pan hd, No. 4 x 1/4	78	161835	Transistor - PNP, 2N1136A. . .	79,85,87
159678	Screw - Mach, pan hd, 4-40 x 1/4.	79	161836	Transformer - Made to Kodak specifications.	81,87
159947	Ring - Retaining, ext, Truarc No. 5133-18 or equiv.	11	161837	Transformer - Made to Kodak specifications.	19,83,87
160027	Washer.	27	161841	Component Board Assembly. . .	81,82
160123	Resistor - 680 Ω 5%, 1/2 W . .	82,87	161842	Amplifier Assembly	78,79
160203	Screw - Mach, pan hd, 2-56 x 7/16	4	161843	Speaker - Made to Kodak specifications.	76
160392	Sound Head Bracket and Bearing Assembly.	46	161845	Amplifier and Exciter Lamp Power Supply Assembly.	19,20
160552	Spacer	12	161846	Name Plate.	78
160553	Lever - Take-up arm release.	11	161847	Plate	4
160555	Spring - Take-up arm release lever.	11	161849	Transistor - PNP, 2N1136. . . .	81,87
160556	Bracket and Pivot Assembly. . .	12	161855	Clamp - Tube, Tinnerman No. C2980S-17-24 or equiv. . .	80
160674	Clip - Cord.	79	161857	Potentiometer - Frequency response control, made to Kodak specifications	82,87
160707	Exciter Lamp Cover Assembly	5,6	161858	Capacitor - Mylar dielectric, .015 MFD 10%, 50 VDC	81,87

Always give PART NUMBER and NAME when ordering parts

PART NO.	PART NAME	FIG.	PART NO.	PART NAME	FIG.
161907	Spring - Shifting roller	30,31,32, 33,35	164405	Lower Sprocket Shaft and Gear Assembly.	59
161911	Case Assembly	71,72	164494	Exciter Lamp Contact Cover Assembly.	43
161925	Spring - Framing shaft	53	164603	Potentiometer - Linear taper, 25 K Ω 30%, Stackpole Carbon No. LW or equiv. . . .	79,80, 85,87
161927	Fastener - Sems, mach, pan hd, 8-32 x 7/16.	16	164604	Clamp - Cable, Weckesser Ny-Grip No. 1 3/8-6 or equiv	80
162128	Belt - Take-up.	1,7	164628	Arm and Bushing Assembly . .	9
162156	Fastener - Sems, mach, pan hd, 8-32 x 1/4.	11	164757	Capacitor - Ceramic disk, .001 MFD 10%, 50 VDC	80,87
162260	Bushing	27	164758	Capacitor - Electrolytic, 40 MFD +100% -10%, 25 VDC, I.E.I. APD076 or equiv	81,87
162261	Fastener - Sems, mach, pan hd, 8-32 x 3/8.	27	164762	Screw - Mach, min hd, 6-32 x 1 1/2.	80
162312	Spacer	5	164763	Standoff	80
162340	Spring - Take-up arm.	12	164770	Lockwasher - Int tooth, .387 min ID x .567 max OD x .018 thk, phos bronze, Shakeproof No. 1920-05 or equiv	79
162402	Name Plate.	6	164789	Spider	66
162403	Spring - Claw retaining.	54	164790	Gear	66
162679	Strip	6	164853	Clip.	26
162750	Bearing	70	165173	Spindle Assembly.	9,10
162751	Bearing	70	165193	Pad	26
162754	Upper Sprocket Shaft Assembly	57	165194	Ring - O.	25
162756	Upper Sprocket Drive Shaft and Gear Assembly.	67	165479	Name Plate.	71
162764	Pinion - Elevating	75	165556	Capacitor - Electrolytic, 25 MFD +100% -10%, 50 VDC, I.E.I. APD087 or equiv	81,87
162815	Lever - Control switch	37	165557	Resistor - W.W., 600 Ω 5%, 5 W	82,87
162816	Knob - Control switch.	1	166044	Belt - Shifting	35
162871	Snubber	6	166260	Plate and Pivot Assembly . . .	13
162891	Resistor - 27 Ω 5%, 1/2 W . . .	82,87	166261	Shutter Drive Arm and Shaft Assembly.	28
162892	Resistor - 33 Ω 5%, 1/2 W . . .	82,87	166263	Framing Knob and Shaft Assembly	53
162893	Transistor - PNP, 2N1038. . . .	81,87	166264	Upper Sprocket Plate, Bearing, and Pin Assembly . .	58
162894	Standoff	80	166441	Bracket & Insulator Assembly.	18
162914	Grille.	2	166488	Pressure Pad Assembly	63,64
162998	Spring - Idler arm	62	166489	Aperture Plate and Pad Assembly	63
163076	Washer.	13	166551	Hinge Assembly (Long)	71
163077	Blower Wheel and Hub Assembly	21	166552	Hinge Assembly (Short). . . .	71
163536	Washer.	75	166893	Transistor - 2N217, 2N408, or 2N1370	81,87
163546	Washer.	68	166898	Pivot	27
163815	Post.	15	167289	Pulley	9
164125	Bracket - Lower mechanism mounting.	72	167290	Pulley	9
164127	Screw - Mach, oval hd, 8-32 x 1	3	761517	Plug - Switchcraft No. S250 or equiv	76
164128	Washer - Finishing, brass, National Lock No. 61-3208 or equiv	3	828667	Lens - Condenser, front	23
164193	Rectifier - Silicon, 200 P.I.V., 750 ma., RCA No. 1N3253 or equiv	20,83,87			
164231	Washer.	27			
164232	Washer.	55			
164261	Shield - Control switch	7			
164262	Shield - Motor fan	7			
164309	Shaft - Pressure roller.	40			
164310	Cam - Exciter lamp release. .	43			
164368	Photocell Mount and Cable Assembly	45			
164369	Plug - H. H. Smith No. 1246 or equiv	45			
164372	Lamp House Baffle and Light Strip Assembly.	17			

PART NO.	PART NAME	FIG.	PART NO.	PART NAME	FIG.
851299	Screw - Mach, pan hd, 6-32 x 3/16	8	861445	Washer.	37
851597	Screw - Tap., Type A, pan hd, No. 6 x 1/2	1,78,79,81	861447	Washer.	75
851927	Setscrew - Hex sock, cup pt, 8-32 x 1/8	26	866521	Resistor - 390 Ω 10%, 1/2 W. .	82,87
			872378	Resistor - 100 Ω 10%, 1/2 W. .	82,87
			872379	Resistor - 1200 Ω 10%, 1/2 W. .	82,87
			872443	Resistor - 12 K Ω 10%, 1/2 W. .	82,87

Corrected to OCTOBER 1969

Parts List No. 636834

***KODAK PAGEANT* SOUND PROJECTOR**

MODEL

BEGINNING WITH SERIAL No.

AV-126-TR

126-C01001

AV-126-TR-R

126-E03230

AV-256-TR

256-C01001

AV-256-TR-R

256-E02600







FIGURE 1



*Quantity used may vary

FIGURE 2




FIGURE 3

*Not included in assembly




FIGURE 4 EXCITOR LAMP COVER ASSEMBLY
- 181152 (TR Models)
- 181153 (TR-R Models)




FIGURE 5

*Quantity used may vary




FIGURE 6 SUPPLY ARM ASSEMBLY AND RELATED PARTS




FIGURE 7 SUPPLY ARM ASSEMBLY - 181013




FIGURE 8 SUPPLY SPINDLE ASSEMBLY - 165173




FIGURE 9 TAKE-UP ARM AND RELATED PARTS




FIGURE 12




FIGURE 10

*Quantity used may vary




FIGURE 11 TAKE-UP SPINDLE ASSEMBLY - 160716




FIGURE 13

TR-R MODELS




FIGURE 14 MECHANISM DRIVE COVER ASSEMBLY - 181157




FIGURE 15 BRACKET AND INSULATOR ASSEMBLY - 166087




FIGURE 15A





FIGURE 16



**FIGURE 17 AMPLIFIER AND EXCITOR LAMP POWER
SUPPLY ASSEMBLY - 166277 (AV-126-TR-R)
- 159636 (AV-126-TR)**




FIGURE 18

AV-256 MODELS




FIGURE 19 AMPLIFIER AND EXCITOR LAMP POWER SUPPLY ASSEMBLY - 166443 (AV-256-TR-R) - 161845 (AV-256-TR)

AV-256 MODELS




FIGURE 20




FIGURE 21




FIGURE 22

*TR-R Models only

TR MODELS

MECHANISM DRIVE MOTOR AND
BRACKET ASSEMBLY (B-1)-159442




FIGURE 23

BLOWER WHEEL AND HUB ASSEMBLY-163077

SCREW-107243

SCREW-122717

SCREW (2)-122715

HOUSING-181163

FASTENER (4)-
159579
(TR-R Models only)

SETSCREW-53768

PLATE-159557

SCREW-122717

FIGURE 25

FIGURE 24

TR-R MODELS

BLOWER MOTOR AND BRACKET ASSEMBLY (B-2)-166128

FAN-166131

FIGURE 25

SETSCREW-851927

LAMP (DS-1), 115-120V

750W-USASI CODE, DDB

1000W-USASI CODE, DFD

LAMP (DS-1), 230V

750W-USASI CODE, DKK

1000W-USASI CODE, DKT

(Listed in Kodak Price Catalog.

Lamp not furnished with TR-R Models.)

REFLECTOR-83373

FIGURE 27

FIGURE 45

FIGURE 43

FIGURE 32

SCREW (4)-122717

SUPPORT AND LAMP CHIMNEY
ASSEMBLY-145169

FIGURE 26






FRONT LENS-828667

SPRING-158638

SPRING-117165

REAR LENS-13775

FIGURE 27 CONDENSER MOUNT ASSEMBLY-121510






FIGURE 33

*Quantity used may vary




FIGURE 34




FIGURE 35




FIGURE 36




FIGURE 37




FIGURE 38




FIGURE 39




FIGURE 40




FIGURE 41




FIGURE 42 SOUND HEAD BRACKET ASSEMBLY - 181006





FIGURE 43

*Quantity used may vary




FIGURE 44




FIGURE 45

*Quantity used may vary




FIGURE 46





FIGURE 47

FIGURE 48




FIGURE 49





FIGURE 50



*Not included in assembly

FIGURE 51 UPPER SPROCKET PLATE ASSEMBLY - 181056




FIGURE 52

LOWER SPROCKET SHAFT AND
GEAR ASSEMBLY-164405




FIGURE 53




FIGURE 54 LOWER SPROCKET PLATE ASSEMBLY - 181055




FIGURE 55




FIGURE 56




FIGURE 57 APERTURE PLATE AND PAD ASSEMBLY - 166489




FIGURE 58 PRESSURE PAD ASSEMBLY - 166488




FIGURE 59 APERTURE PLATE ASSEMBLY - 138144




FIGURE 60




FIGURE 61




FIGURE 62




FIGURE 63





FIGURE 64 MECHANISM HOUSING ASSEMBLY - 181004



**FIGURE 65 CASE ASSEMBLY - 181553 (AV-126-TR)
- 181554 (AV-256-TR)
- 182489 (AV-126-TR-R)
- 182490 (AV-256-TR-R)**




FIGURE 66




FIGURE 67




FIGURE 68






FIGURE 69



HOW TO DETERMINE NO. 1 SPEAKER TERMINAL
IF THE CONE MOVES FORWARD WHEN A FLASHLIGHT BATTERY IS PLACED ACROSS THE SPEAKER TERMINALS, THE TERMINAL CONNECTED TO THE POSITIVE POLE OF THE BATTERY WILL BE THE NO. 1 SPEAKER TERMINAL

IMPORTANT
CABLE SHIELD MUST ALWAYS BE CONNECTED TO SPEAKER TERMINAL NO. 1. THE LOCATION OF THE NO. 1 AND NO. 2 SPEAKER TERMINALS MAY BE REVERSED FROM THOSE SHOWN.


FIGURE 70 SPEAKER AND CABLE WIRING DIAGRAM (FEBRUARY 1968)



*Old plate must be returned to Kodak before a new plate will be supplied.

FIGURE 71

AV-126 MODELS



AV-126 MODELS





FIGURE 73

FIGURE 74


Always give PART NUMBER and NAME when ordering parts

AV-126 MODELS




AMPLIFIER COMPONENT BOARD ASSEMBLY - 159436 (Also see Figure 75)

AV-126 MODELS



AMPLIFIER COMPONENT BOARD ASSEMBLY - 159436

AV-256 MODELS



**FIGURE 76 AMPLIFIER ASSEMBLY - 181895 (AV-256-TR)
- 181147 (AV-256-TR-R)**

AV-256 MODELS





FIGURE 77

FIGURE 78


AV-256 MODELS



AMPLIFIER COMPONENT BOARD ASSEMBLY - 161841

FIGURE 79


AV-256 MODELS



AMPLIFIER COMPONENT BOARD ASSEMBLY - 161841

Always give PART NUMBER and NAME when ordering parts


TR MODELS



WIRING HOOKUP (FEBRUARY 1968)
FOR
SWITCH (S-3)

FIGURE 80

TR-R MODELS



WIRING HOOKUP (FEBRUARY 1968)
FOR
SWITCH (S-3)

FIGURE 81

AV-126 MODELS




FIGURE 82

AMPLIFIER AND EXCITER LAMP
 POWER SUPPLY ASSEMBLY (FEBRUARY 1968)

AV-256 MODELS





FIGURE 83

AMPLIFIER AND EXCITER LAMP
 POWER SUPPLY ASSEMBLY (FEBRUARY 1968)

TR MODELS




- * DISCONNECT TO REMOVE AMPLIFIER (AMPLIFIER WILL STILL OPERATE)
- ▲ DISCONNECT TO REMOVE AMPLIFIER COMPLETELY
- DISCONNECT TO REMOVE MECHANISM

SWITCH AND TERMINAL CONNECTIONS (FEBRUARY 1968)

FIGURE 84

TR-R MODELS



- * DISCONNECT TO REMOVE AMPLIFIER (AMPLIFIER WILL STILL OPERATE)
- ▲ DISCONNECT TO REMOVE AMPLIFIER COMPLETELY
- DISCONNECT TO REMOVE MECHANISM


COLOR CODE
K=BLACK
N=BROWN
R=RED
O=ORANGE
Y=YELLOW

G=GREEN
B=BLUE
V=VIOLET
A=GRAY
W=WHITE

SWITCH AND TERMINAL CONNECTIONS (FEBRUARY 1968)

FIGURE 85


AV-126 MODELS



AMPLIFIER WIRING DIAGRAM (FEBRUARY 1968)

FIGURE 86


AV-256 MODELS



AMPLIFIER WIRING DIAGRAM (FEBRUARY 1968)

FIGURE 87

AV-126 MODELS




Numbers in circles refer to voltage check points.

**AMPLIFIER COMPONENT BOARD
(FEBRUARY 1968)**

FIGURE 88

AV-256 MODELS



Numbers in circles refer to voltage check points

AMPLIFIER COMPONENT BOARD (FEBRUARY 1968)

PART NO.	DESCRIPTION	FIG.	PART NO.	DESCRIPTION	FIG.
7514	Ball - Carbon steel, 3/16	48	108546	Nut - Flywheel.	13
12177	Ball - Carbon steel, 1/8	48	109571	Setscrew - Hex sock, cone pt, 4-40 x 1/8	35
13775	Lens - Condenser, rear.	27	110005	Rivet - (TR-R Models).	14
25739	Washer - Flywheel shaft (TR-R Models)	13	116266	Rivet	4,15,15A
25883	Ball - Carbon steel, 3/32	7	117165	Spring - Condenser lens separator.	27
26299	Nut - Hex, 8-32 (AV-126 Models)	17	117543	Plate - Claw pivot.	49
31576	Nut - Hex., 8-32	9,20	117547	Eccentric - Stroke adjusting. .	49
33992	Lockwasher - Int tooth, No. 10	30	117548	Pivot - Framing lever.	47
37266	Washer - 5/32 x 3/8 x .049 (AV-256 Models)	77	117549	Spacer - Claw pivot plate. . . .	49
37492	Nut - Hex, 5/16-24	10	117713	Cup - Damping bearing	55
42533	Nut - Hex, 6-32	66,77	117725	Worm - Shutter shaft.	63
42745	Nut - Hex, 10-32 (AV-256 Models)	77	117736	Sound Optics Assembly	40
42874	Lockwasher - Int tooth, No. 6 .	28,34	117762	Spring - Sprocket roller.	52,54
45322	Nut - Hex, 4-40	38,40	119395	Washer - Spacer.	33
46236	Washer - Spacer.	10	119416	Grommet (TR-R Models)	14
47317	Lockwasher - Int tooth, No. 8 .	9,17,21	120213	Sleeve - Mechanism support bracket	14,15
48023	Washer - Spacer.	9	120243	Shaft - Rewind shift plate. . . .	61
48969	Washer - .010	45	120335	Washer - Lamp socket mounting	43
50088	Setscrew - Hex sock, cup pt, 1/4-20 x 3/4.	12	120389	Rivet	59
53768	Setscrew - Hex sock, cup pt, 8-32 x 1/4	22,24	120391	Guide - Aperture plate.	59
55776	Lockwasher - Int tooth, No. 6 .	21,51	120392	Spring - Side guide	59
56786	Washer - 13/32 x 13/16 x .065	2	120393	Rivet	59,62
57155	Nut - Hex, 4-40	43	120422	Washer - Retaining.	14,15,22,44
58694	Plunger - Spindle	8,11	120438	Link - Pressure roller equalizing	36
58696	Spring - Spindle	8,11	120444	Grommet.	5,9,14,15
69682	Lockwasher - Int tooth, No. 6 .	66	120445	Sleeve.	5,9,22
70928	Setscrew - Hex. sock. hd, cup pt, 6-32 x 1/4	71	120456	Bearing - Ball	35
71638	Clamp - Lamp socket	43	120466	Spring - Sound optics bracket .	37
74906	Washer - Spacer.	61	120468	Eccentric - Sound optics bracket	38
75847	Washer - 1/4 x 9/16 x .065. . .	2	120471	Post - Sound optics mount adjusting	40
76529	Screw - Cap, hex sock. hd, 10-32 x 3/8	30	120475	Spring - Sound optics mount . .	40
77219	Washer - Bearing retaining . .	7	120476	Nut - Sound optics post	40
78621	Lockwasher - Int tooth, No. 10 (AV-256 Models)	77	120486	Spring - Sprocket guard detent	54
78624	Washer - Shutter shaft.	45	120642	Washer - Retaining.	22,52,54
79097	Washer - Framing lever	47	120672	Clip - Reel spindle	8,11
80753	Lockwasher - Int tooth, 3/8 . .	72,76	120674	Bearing - Ball	63
80969	Washer - Spacer.	10	120986	Washer - Flywheel shaft	35
83373	Reflector - Lamp	26	121507	Sprocket Roller Plate Assembly	52,54
86892	Washer - Retaining.	38	121510	Condenser Mount Assembly . .	27
87777	Screw - Lamp socket mounting	43	121517	Pressure Arm Assembly	36
88937	Plate - Handle reinforcement .	67	122233	Washer - Spacer.	6
89342	Lockwasher - Ext tooth, No. 8 (AV-256 Models)	20	122608	Bracket - Speaker cable.	69
90630	Washer - 3/32 x 1/4 x .020. . .	55	122666	Screw - Pan hd, 4-40 x 3/8. . .	38
92950	Washer - .005	45	122686	Screw - Wood, rd hd, No. 8 x 1/2	69
93847	Washer - Spacer.	29	122691	Screw - Pan hd, 6-32 x 1/4 (TR-R Models)	22
95533	Washer - 5/32 x 3/8 x .049 (TR-R Models)	72,76	122706	Screw - Pan hd, 8-32 x 3/8. . .	9
97826	Ring - Retaining.	63	122713	Screw - Pan hd, 6-32 x 1/2. . .	1,14,16
107101	Setscrew - Hex sock, cone pt, 5-40 x 3/16	4,53,60,63	122714	Screw - Pan hd, 8-32 x 1/2. . .	1
107213	Screw - Min. hd, 8-32 x 7/16 .	21	122715	Screw - Pan hd, 6-32 x 3/8. . .	24,53
107243	Screw - Flat hd, 4-40 x 3/16. .	24	122717	Screw - Pan hd, 4-40 x 3/16. .	4,24,26,37,50
107606	Ring - Retaining.	29	122718	Screw - Pan hd, 6-32 x 5/8. . .	51
			122720	Screw - Pan hd, 4-40 x 5/16. .	38
			122721	Screw - Pan hd, 6-32 x 5/16. .	51,61
			122727	Screw - Pan hd, 10-32 x 1/2 (AV-256 Models)	77

PART NO.	DESCRIPTION	FIG.	PART NO.	DESCRIPTION	FIG.
122730	Screw - Pan hd, 4-40 x 5/8. . .	39,43	129467	Anchor - Loop restorer spring	37
122767	Screw - Pan hd, 10-32 x 1 . . .	2	129757	Ring - Retaining.	62
122778	Screw - Pan hd, 6-32 x 1	4	129870	Screw - Pan hd, 2-56 x 5/64. .	58
122791	Screw - Tap., Type A, pan hd, No. 10 x 3/4.	2	130179	Loop Former Arm and Shaft Assembly.	37
122808	Screw - Pan hd, 4-40 x 1/8. . .	50	130340	Pin - Spring, 1/16 x 3/8. . . .	7
122814	Screw - Pan hd, 2-56 x 3/16. .	40,55	130610	Clip - Motor grounding	22
122992	Nut - Hex, 6-32	28,34	131075	Ring - Retaining.	31
123363	Washer - Spacer.	13	131241	Plate - Elevating mechanism .	68
123633	Screw - Tap., Type B, pan hd, No. 2 x 1/8.	4,14	131263	Washer - Spacer.	68
123639	Spring - Handle	67	131268	Washer - Elevating mechanism	68
123851	Belt - Rewind.	1	131283	Screw - Tap., Type F, pan hd, 6-32 x 3/8 (TR-R Models). . .	72,76
123856	Washer - Spacer.	6	131363	Spring - Reverse drive	60
123857	Washer - Spacer.	6	131369	Actuator - Reverse take-up clutch	60
123869	Support - Lower loop.	50	131544	Spring - Damping roller. . . .	55
123885	Spring - Rewind shaft lever detent	62	131545	Setscrew - Hex sock., oval pt, 4-40 x 5/8	40
123898	Spacer - Fan housing.	21	131546	Spring - Pressure roller	36
123970	Screw - Pan hd, 6-32 x 1-3/4 .	21	131563	Clutch and Bushing Assembly .	44
124128	Lockwasher - Int tooth, alternate twist, 3/8	6	131564	Bracket and Stud Assembly. . .	44
124214	Washer - Spacer.	13	132036	Sound Optics Bracket Assembly	40
124338	Screw - Tap., Type F, pan hd, 10-32 x 3/8	76	132172	Inner Shutter Blade and Studs Assembly.	45
124404	Sleeve - Mechanism mounting post	2	132173	Outer Shutter Blade and Studs Assembly.	45
124606	Damping Arm Assembly.	55	134124	Shutter Assembly	45
124832	Screw - Min hd, 2-56 x 3/16. .	41,51,53	137362	Ring - Retaining.	52,54
125104	Spring - Claw.	48	137410	Rivet - (AV-126 Models)	72
125348	Washer - Retaining (TR-R Models)	14	137413	Rivet - Connector (AV-256 Models)	76
125349	Washer - Case bracket	4,65	138142	Baffle - Aperture plate	57
125789	Ball - Nylon, 3/16.	50,52,54	138144	Aperture Plate Assembly. . . .	59
125854	Grommet - Mechanism mounting post.	2	138229	Washer - Mechanism mounting	3
126284	Pawl - Pulley and Ratchet Assembly.	9	138252	Ring - Retaining.	35
126319	Gear - Reverse drive differential.	60	138254	Ring - Retaining.	68
126321	Gear and Sprocket Drive Assembly.	60	138688	Grommet.	22
126326	Pulley - Rewind drive	61	139481	Pad - Claw pivot, small. . . .	48
126332	Chain - Reverse flywheel drive	35	140102	Washer - Spacer.	29
126751	Plate - Sprocket.	51,53	140110	Washer - Spacer.	9
126752	Sprocket - Hub.	51,53	140118	Window - Excitor lamp	4
126841	Collar - Upper sprocket hub. .	51	141285	Pin - Spring, stain. steel, 3/32 x 1/4	8,11
126842	Stud - Rewind plate.	61	142849	Washer - Lamp socket mounting	43
127184	Stud - Sprocket drive.	51	142850	Screw - Lamp adjusting.	5
127868	Spring - Pulldown in-and-out .	46	143177	Pivot - Supply arm	6
128527	Ring - Retaining.	44,47	143179	Screw - Cover	1
128713	Washer - Shutter shaft.	45	143206	Fan - Mechanism drive motor.	22
128967	Rivet - Hinge, latch.	65	144638	Ring - Retaining.	47
129404	Roller - Pressure.	36	145169	Support and Lamp Chimney Assembly.	26
129413	Spring - Pressure pad.	58	145264	Claw Assembly.	48
129414	Post - Pressure pad hinge . . .	57	146581	Washer - Retaining.	31
129415	Spring - Gate mounting	57	146816	Screw - Pan hd, 8-32 x 3/8 (AV-126 Models).	17
129457	Spring - Lens retaining	50	147657	Speaker Cable and Plug Assy .	69
129458	Catch - Film gate.	50	147658	Speaker - (AV-126 Models). . .	69
129461	Spring - Loop restorer	37	148960	Roller - Damping	55
129464	Pivot - Loop former arm. . . .	37	149578	Cam - In-and-out	45
129465	Handle - Loop restorer	36	149738	Washer - Rewind plate shaft. .	61

PART NO.	DESCRIPTION	FIG.	PART NO.	DESCRIPTION	FIG.
150124	Fastener - Sems, pan hd, 4-40 x 3/16	36,46,55	159530	Bracket - Toggle	34
150125	Fastener - Sems, pan hd, 4-40 x 5/16	21,47,72,76	159531	Arm - Toggle plate	34
151409	Shaft - Shutter	63	159532	Plate - Toggle	34
151913	Screw - Tap., Type A, pan hd, No. 8 x 5/8.	69	159536	Link - Toggle.	34
151951	Fastener - Sems, pan hd, 6-32 x 3/16	46,48	159539	Stud	28
151952	Fastener - Sems, pan hd, 6-32 x 3/8	17,19	159547	Yoke - Switch bracket	33
152627	Screw - Tap., Type F, pan hd, 4-40 x 3/16 (AV-256 Models).	78	159548	Screw - Switch bracket	33
153360	Roller - Belt shifting lever.	31	159549	Plate - Switch bracket.	34
154621	Washer - Control knob.	71	159552	Motor Pulley Assembly (TR Models).	23
155047	Screw - Oval hd, 6-32 x 5/8	65,68	159554	Stud - Toggle plate	34
155055	Bracket - Elevator	68	159557	Plate - Fan housing.	24
155056	Plate - Elevator spacer.	68	159563	Spring - Belt shifting.	31
155058	Rack - Elevating mechanism.	68	159571	Idler - Take-up belt	61
155059	Insert - Elevating knob	68	159574	Lever - Framing	47
155065	Bearing - Elevating.	68	159576	Shaft - Take-up belt idler.	61
155270	Flywheel Assembly.	13	159577	Ring - Retaining.	9,61
155274	Hub - Upper sprocket	51	159579	Fastener - Sems, pan hd, 6-32 x 1/4	24,34,44,62
155278	Flywheel Shaft and Sound Drum Assembly.	35	159580	Link - Rewind	62
155282	Ratchet - Flywheel shaft	35	159581	Lever - Rewind	62
155285	Spacer	13	159582	Shaft - Rewind lever	62
155484	Insert - Control knob.	71	159583	Spacer - Upper sprocket plate.	51
155590	Braking Spring and Button Assembly.	36	159587	Roller - Film guide.	4,56
155815	Hub - Lower sprocket	53	159588	Shaft - Film guide roller	4
156258	Bearing - Sound head bracket	42	159591	Shutter Drive Pulley Assembly (TR Models).	29
156850	Nut - Switch bracket	33	159595	Support - Upper loop.	50
157636	Cover - Sound optics adjusting lever.	39	159605	Arm - Idler roller bearing.	56
157866	Fastener - Sems, pan hd, 2-56 x 3/16	57	159607	Pin - Idler arm pivot.	56
158002	Setscrew - Hex sock., cup pt, 4-40 x 3/32	51	159611	Spring - Upper sprocket guard detent	52
158416	Fastener - Sems, pan hd, 6-32 x 1/2	30	159636	Amplifier and Excitor Lamp Power Supply Assembly (AV-126-TR)	17
158638	Spring - Condenser lens.	27	159657	Belt - Motor drive pulley.	21
159164	Clamp - Cable (TR-R Models).	72,76	159667	Plate - Take-up reel arm tension adjusting.	10
159423	Washer - Spacer.	72,76	159670	Spacer	1
159431	Washer - Shoulder	72,76	159671	Screw - Tap., Type A, pan hd, No. 4 x 1/4.	71
159432	Washer - 1/4 x 1/2 x 1/16	72,76	159947	Ring - Retaining.	9
159433	Washer - Shoulder	72,76	160027	Washer - Spacer.	28
159434	Washer - 3/8 x 5/8 x 1/16	72,76	160203	Screw - Pan hd, 2-56 x 7/16.	1
159436	Amplifier Component Board Assembly (AV-126 Models).	74,75	160552	Spacer	10
159441	Screw - Min hd, 6-32 x 1-3/8	73,77	160555	Spring - Take-up arm release lever.	9
159465	Fastener - Sems, pan hd, 8-32 x 1.	37	160674	Connector - Wire	72,76
159512	Grille - Case, front.	65	160716	Take-up Spindle Assembly	11
159513	Bracket - Handle	66	160724	Switch Bracket Assembly.	34
159514	Washer.	65	160726	Belt Shifting Lever Assembly	31
159516	Lock - Case cover	65	160761	Sprocket and Pawl Assembly.	35
159521	Post - Cover handle	67	161589	Grille - Case, side	65
159522	Pin - Case handle.	66,67	161749	Shaft - Idler roller	56
159523	Plate - Handle post.	66,67	161752	Washer - Spacer.	10,33
159529	Spring - Toggle	34	161755	Washer - Spacer.	29
			161756	Washer - Spacer.	29
			161793	Pivot - Take-up reel arm.	10
			161810	Rewind Plate and Guide Assy	62
			161841	Amplifier Component Board Assembly (AV-256 Models).	78,79


PART NO.	DESCRIPTION	FIG.	PART NO.	DESCRIPTION	FIG.
161843	Speaker - (AV-256 Models) . . .	69	166131	Fan - Blower motor	
161845	Amplifier and Excitor Lamp			(TR-R Models)	25
	Power Supply Assembly		166136	Shutter Drive Pulley Assembly	
	(AV-256-TR)	19		(TR-R Models)	29
161907	Spring - Shifting roller	31	166141	Grille - Mechanism drive	
161925	Spring - Framing shaft	47		cover (TR-R Models)	14
162260	Bushing - Arm and Shaft Assy.	28	166143	Bracket (TR-R Models)	15A
162261	Fastener - Sems, pan hd,		166151	Bracket - Mechanism support.	15
	8-32 x 3/8	21,28	166260	Plate and Pivot Assembly.	9
162312	Spacer - Excitor lamp cover. .	4	166264	Upper Sprocket Plate, Bearing,	
162403	Spring - Claw retaining	48		and Pin Assembly	52
162456	Board - Switch (TR-R Models)	15A	166277	Amplifier and Excitor Lamp	
162750	Bearing - Mechanism Housing			Power Supply Assembly	
	Assembly.	64		(AV-126-TR-R).	17
162751	Bearing - Mechanism Housing		166443	Amplifier and Exciter Lamp	
	Assembly.	64		Power Supply Assembly	
162754	Upper Sprocket Shaft Assembly	51		(AV-256-TR-R).	19
162756	Upper Sprocket Drive Shaft		166488	Pressure Pad Assembly.	58
	and Gear Assembly	61	166489	Aperture Plate and Pad Assy .	57
162764	Pinion - Elevating.	68	166899	Pivot - Belt shifting lever . . .	31
162815	Lever - Control switch	33	167229	Spring - Coupling (TR-R Models)	22
162894	Standoff - Circuit board.	73,77	167290	Pulley - Supply arm	7
162914	Grille - Case, bottom	2	168729	Washer - Spacer.	37
162998	Spring - Idler arm	56	169626	Pulley and Ratchet Assembly .	9
163077	Blower Wheel and Hub Assembly	24	170458	Shutter Drive Arm and Pulley	
163536	Washer - Elevating mechanism	68		Assembly (TR Models).	29
163546	Washer - Spacer.	62	170488	Pivot - Arm and Shaft Assembly	28
163815	Post - Mechanism mounting . .	12	170807	Post - Case handle	66
164125	Bracket - Lower mechanism		171026	Nut - Lock, 1/4-28 LH.	45
	mounting	65	171493	Eccentric - Motor mounting . .	22
164127	Screw - Oval hd, 8-32 x 1.	3	171759	Shutter Weight Assembly	45
164128	Washer - Mechanism mounting	3	171760	Shutter Drive Arm and Shaft	
164231	Washer - Spacer.	28		Assembly.	29
164232	Washer - Spacer.	49	172250	Lever - Take-up arm release.	9
164261	Shield - Control switch	5	172252	Pin - Take-up arm	10
164262	Shield - Motor fan.	5	172254	Spring - Take-up arm	10
164309	Shaft - Pressure roller	36	172287	Spacer	30
164310	Cam - Excitor lamp release. .	39	172561	Control Switch Cam and	
164368	Silicon Solar Cell Mount			Pinion Assembly.	32
	and Cable Assembly.	41	172991	Support - Flywheel	21
164369	Plug - Cable Assembly	41	173475	Washer - Spacer.	2
164405	Lower Sprocket Shaft and		173555	Fastener - Sems, pan hd,	
	Gear Assembly.	53		4-40 x 3/8	49
164494	Excitor Lamp Contact Cover		174929	Knob Assembly.	71
	Assembly.	39	174930	Elevating Knob Assembly. . . .	68
164762	Screw - Min hd, 6-32 x 1 1/2		175269	Pad - Claw pivot, large	48
	(AV-256 Models).	77	177215	Hinge Assembly	65
164763	Standoff - Amplifier mounting		177274	Washer - Spacer.	9
	(AV-256 Models).	77	177739	Clamp - Capacitor C-15	
164769	Terminal - (AV-126 Models). .	72,76		(AV-256 Models).	77
164770	Lockwasher - Connector	72,76	177992	Washer - Spacer.	22
164789	Spider - Reverse	60	178762	Clamp - Capacitor C-13	
164790	Gear - Reverse drive	60		(AV-256 Models).	77
164853	Clip - Oil catcher pad		178763	Screw - Pan hd, 8-32 x 3/4. . .	22
	(TR Models).	23	178977	Belt - Shifting	21
165173	Supply Spindle Assembly	8	179131	Spring - Sprocket drive	51
165193	Pad - Oil catcher (TR Models)	23	179307	Motor Pulley Assembly	
165194	Ring - Motor pulley			(TR-R Models)	22
	(TR Models).	23	180981	Handle - Case	66,67
166086	Insulator - (AV-256 Models). .	15	180983	Medallion - KODAK PAGEANT	65
166087	Bracket and Insulator		180984	Plate - 25 Watt (AV-256 Models)	65
	Assembly (AV-256-TR)	15	181004	Mechanism Housing Assembly	64

Always give PART NUMBER and NAME when ordering parts

PART NO.	DESCRIPTION	FIG.	PART NO.	DESCRIPTION	FIG.
181006	Sound Head Bracket Assembly	42	181160	Lamphouse Baffle and Light Strip Assembly (TR Models) .	16
181009	Bracket and Pivot Assembly..	10	181162	Plate - Supply arm	6
181010	Take-Up Arm, Pin and Bearing Assembly.	10	181163	Housing - Fan	24
181011	Plate - Take-up arm.	10	181164	Roller - Loop restorer	36
181013	Supply Arm Assembly	7	181165	Belt - Take-up.	1
181014	Arm and Bushing Assembly . .	7	181367	Plate - Lamphouse cover (AV-256-TR)	1
181050	Cover - Lamphouse.	1	181368	Plate - Lamphouse cover (AV-256-TR-R).	1
181051	Plate - Lamphouse cover (AV-126-TR)	1	181369	Plate - Control panel (AV-126-TR)	71
181052	Plate - Lamphouse cover (AV-126-TR-R).	1	181370	Plate - Control panel (AV-126-TR-R).	71
181054	Knob - Threading	63	181371	Plate - Control panel (AV-256-TR)	71
181055	Lower Sprocket Plate Assembly	54,56	181372	Plate - Control panel (AV-256-TR-R).	71
181056	Upper Sprocket Plate Assembly	51	181552	Framing Knob and Shaft Assy .	47
181057	Roller - Sprocket	52,54	181553	Case Assembly (AV-126-TR) .	65
181058	Knob - Control lever.	4	181554	Case Assembly (AV-256-TR) .	65
181059	Amplifier Assembly (AV-126-TR)	72	181895	Amplifier Assembly (AV-256-TR)	76
181098	Foot - Case bottom.	2	182043	Cam - Pulldown	45
181147	Amplifier Assembly (AV-256-TR-R).	76	182489	Case Assembly (AV-126-TR-R)	65
181148	Amplifier Assembly (AV-126-TR-R).	72	182490	Case Assembly (AV-256-TR-R)	65
181149	Guide - Film	72,76	182810	Strip - Felt	4
181152	Exciter Lamp Cover Assembly (TR Models).	4	183615	Snubber - Felt	4
181153	Exciter Lamp Cover Assembly (TR-R Models) . . .	4	184118	Spring - Shutter weight return.	45
181155	Plate - Control switch (TR Models).	4	185605	Cover - Elevation foot	68
181156	Plate - Control switch (TR-R Models).	4	761517	Plug - Speaker.	69
181157	Mechanism Drive Cover Assembly (TR-R Models) . . .	14	828667	Lens - Condenser, front.	27
181158	Cover - Mechanism drive (TR-R Models).	14	851299	Screw - Pan hd, 6-32 x 3/16..	6
181159	Plate - Mechanism drive cover (TR-R Models).	14	851488	Screw - Pan hd, 6-32 x 1 3/4 .	77
			851597	Screw - Tap., Type A, pan hd, No. 6 x 1/2.	71,72,76,78
			851816	Washer - Spacer.	9
			851927	Setscrew - Hex sock., cup pt, 8-32 x 1/8	22,25
			852562	Setscrew - Hex sock., cup pt, 8-32 x 3/16	32
			861447	Washer - Elevating mechanism.	68

Always give PART NUMBER and NAME when ordering parts

AV-126-TR MODELS



Measure dc voltages with high impedance voltmeter with no input signal and no external load.

Numbers in circles refer to voltage check points.


SCHEMATIC CIRCUIT (FEBRUARY 1968)

CODE	PART NO.	DESCRIPTION	FIG.	CODE	PART NO.	DESCRIPTION	FIG.	CODE	PART NO.	DESCRIPTION	FIG.
B-1	159442	Mechanism Drive Motor and Bracket Assembly	23	CR-3	164193	750mA, 200PIV Diode	18	R-7	119816	1k Ω ±10%, 1/2W	75
C-1	161022	25 μ F, 10Vdc, Electrolytic.	74	CR-4	164193	750mA, 200PIV Diode	18	R-8	126900	10k Ω ±10%, 1/2W	75
C-2	161022	25 μ F, 10Vdc, Electrolytic.	74	CR-5	159444	Diode Stabistor S320G	75	R-9	119816	1k Ω ±10%, 1/2W	75
C-3	152129	.01 μ F ±10%, 50Vdc	74	DS-1		Projection Lamp	26	R-10	152753	7.5k Ω ±5%, 1/2W	75
C-4	161022	25 μ F, 10Vdc, Electrolytic.	74	DS-2		Photocell Excitor Lamp.	5	R-11	126394	4.7k Ω ±10%, 1/2W	75
C-5	159408	75 μ F, 25Vdc, Electrolytic.	74	J-2	147832	Speaker Jack	72	R-12	168043	62k Ω ±5%, 1/2W	75
C-6	159408	75 μ F, 25Vdc, Electrolytic.	74	J-3	159429	Phone Jack	72	R-13	126401	150 Ω ±10%, 1/2W	75
C-7	159411	50pF ±10%, 50Vdc min	74	J-4	159430	Microphone Connector	72	R-14	159406	220 Ω ±10%, 1/2W	75
C-8	159412	60 μ F, 6Vdc, Electrolytic.	74	J-5	159429	Solar Cell Jack	72	R-15	119816	1k Ω ±10%, 1/2W	75
C-9	159410	125 μ F, 50Vdc, Electrolytic.	74	J-6	145170	Projection Lamp Socket	43	R-16	870569	2.7k Ω ±10%, 1/2W	75
C-10	159413	10 μ F, 50Vdc, Electrolytic.	74	P-1	159551	Power Cord	1	R-17	872379	1.2k Ω ±10%, 1/2W	75
C-11	160673	.68 μ F ±10%, 100Vdc	74	Q-1	184574	Transistor 2N5366	74	R-18	154868	500 Ω ±10%, 2W, Wirewound	18
C-12	162883	60 μ F, 50Vdc, Electrolytic.	74	Q-2	184574	Transistor 2N5366	74	R-19	153447	200 Ω ±5%, 1/2W	75
C-13	159416	Capacitor	73	Q-3	166893	Transistor 2N217, 2N408, or 2N1370.	74	R-20	153447	200 Ω ±5%, 1/2W	75
C-14	159634	1300 μ F, 35Vdc, Electrolytic.	17	Q-4	184574	Transistor 2N5366	74	R-21	120506	15k Ω ±10%, 1/2W	75
C-15	159634	1300 μ F, 35Vdc, Electrolytic.	17	Q-5	166893	Transistor 2N217, 2N408, or 2N1370.	74	R-22	120508	68k Ω ±10%, 1/2W	75
C-16	159416	Capacitor	73	Q-6	170542	Transistor 2N1102	74	R-23	126903	22k Ω ±10%, 1/2W	75
C-17	161022	25 μ F, 10Vdc, Electrolytic.	74	Q-7	159426	Transistor 2N307 or B10394.	72	R-24	159406	220 Ω ±10%, 1/2W	75
C-18	159418	100pF ±10%, 50Vdc	74	Q-8	159426	Transistor 2N307 or B10394.	72	R-25	159407	47 Ω ±10%, 2W	73
C-20	161020	.005 μ F ±10%, 50Vdc	74	QS-7	159422	Transistor Socket	72	R-26	159633	25 Ω ±10%, 25W	18
C-21	159420	.004 μ F ±10%, 50Vdc	74	QS-8	159422	Transistor Socket	72	R-27	159427	5k Ω Volume Control.	75
C-22	161021	.0018 μ F ±10%, 50Vdc	74	R-1	126101	470k Ω ±10%, 1/2W	75	R-28	159428	Bias Control, 500k Ω	75
C-23	161021	.0018 μ F ±10%, 50Vdc	74	R-2	78671	47k Ω ±10%, 1/2W	75	R-29	154866	5.6k Ω ±10%, 1/2W	75
C-24	159418	100pF ±10%, 50Vdc	74	R-3	160558	3.6k Ω ±5%, 1/2W	75	R-30	120504	33k Ω ±10%, 1/2W	75
C-25	159409	.027 μ F, 100Vdc	74	R-4	126900	10k Ω ±10%, 1/2W	75	R-31	160672	.25 Ω ±10%, 1W, Wirewound	73
C-26	159414	.033 μ F, 100Vdc	74	R-5	136709	47 Ω ±10%, 1/2W	75	R-32	160672	.25 Ω ±10%, 1W, Wirewound	75
C-27	159419	.047 μ F, 100Vdc	74	R-6	78671	47k Ω ±10%, 1/2W	75	R-34	164603	Potentiometer, 25k Ω	72
C-29	159413	10 μ F, 50Vdc, Electrolytic.	74					S-1	186949	Input Selector Switch	72
CB-1	151383	Circuit Breaker	72					S-2	159435	Tone Control Switch	74
CR-1	164193	750mA, 200PIV Diode	18					S-3	159533	Projector Control Switch	32
CR-2	164193	750mA, 200PIV Diode	18					S-4 } J-1 }	159445	{ Amplifier Control Switch { Threadlamp Socket	72
								T-1	159637	Power Transformer	17

PART NUMBERS IN NUMERICAL ORDER

NUMBER	CODE	NUMBER	CODE	NUMBER	CODE	NUMBER	CODE	NUMBER	CODE	NUMBER	CODE	NUMBER	CODE	NUMBER	CODE
78671	R-2	126900	R-4	154866	R-29	159413	C-10	159426	Q-7	159533	S-3	161021	C-22	164603	R-34
78671	R-6	126900	R-8	154868	R-18	159413	C-29	159426	Q-8	159551	P-1	161021	C-23	166893	Q-3
119816	R-7	126903	R-23	159406	R-14	159414	C-26	159427	R-27	159633	R-26	161022	C-1	166893	Q-5
119816	R-9	136709	R-5	159406	R-24	159416	C-13	159428	R-28	159634	C-14	161022	C-2	168043	R-12
119816	R-15	145170	J-6	159407	R-25	159416	C-16	159429	J-3	159634	C-15	161022	C-4	170542	Q-6
120504	R-30	147832	J-2	159408	C-5	159418	C-18	159429	J-5	159637	T-1	161022	C-17	184574	Q-1
120506	R-21	151383	CB-1	159408	C-6	159418	C-24	159430	J-4	160558	R-3	162883	C-12	184574	Q-2
120508	R-22	152129	C-3	159409	C-25	159419	C-27	159435	S-2	160672	R-31	164193	CR-1	184574	Q-4
126101	R-1	152753	R-10	159410	C-9	159420	C-21	159442	B-1	160672	R-32	164193	CR-2	186949	S-1
126394	R-11	153447	R-19	159411	C-7	159422	QS-7	159444	CR-5	160673	C-11	164193	CR-3	870569	R-16
126401	R-13	153447	R-20	159412	C-8	159422	QS-8	159445	S4, J-1	161020	C-20	164193	CR-4	872379	R-17

AV-126-TR-R MODELS



Measure dc voltages with high impedance voltmeter with no input signal and no external load.

Numbers in circles refer to voltage check points.


SCHEMATIC CIRCUIT (FEBRUARY 1968)

CODE	PART NO.	DESCRIPTION	FIG.	CODE	PART NO.	DESCRIPTION	FIG.	CODE	PART NO.	DESCRIPTION	FIG.
B-1	166147	Motor and Bracket Assembly...	22	CR-3	164193	750mA, 200PIV Diode	18	R-8	126900	10kΩ ±10%, 1/2W	75
B-2	166128	Blower Motor and Bracket Assembly.	25	CR-4	164193	750mA, 200PIV Diode	18	R-9	119816	1kΩ ±10%, 1/2W	75
C-1	161022	25μF, 10Vdc, Electrolytic.	74	CR-5	159444	Diode Stabistor S320G	75	R-10	152753	7.5kΩ ±5%, 1/2W	75
C-2	161022	25μF, 10Vdc, Electrolytic.	74	DS-1		Projection Lamp	26	R-11	126394	4.7kΩ ±10%, 1/2W	75
C-3	152129	.01μF ±10%, 50Vdc	74	DS-2		Photocell Excitor Lamp.	5	R-12	168043	62kΩ ±5%, 1/2W	75
C-4	161022	25μF, 10Vdc, Electrolytic.	74	J-2	147832	Speaker Jack	72	R-13	126401	150Ω ±10%, 1/2W	75
C-5	159408	75μF, 25Vdc, Electrolytic.	74	J-3	159429	Phono Jack	72	R-14	159406	220Ω ±10%, 1/2W	75
C-6	159408	75μF, 25Vdc, Electrolytic.	74	J-4	159430	Microphone Connector	72	R-15	119816	1kΩ ±10%, 1/2W	75
C-7	159411	50pF ±10%, 50Vdc min.	74	J-5	159429	Solar Cell Jack	72	R-16	870569	2.7kΩ ±10%, 1/2W	75
C-8	159412	60μF, 6Vdc, Electrolytic.	74	J-6	145170	Projection Lamp Socket	43	R-17	872379	1.2kΩ ±10%, 1/2W	75
C-9	159410	125μF, 50Vdc, Electrolytic.	74	P-1	159551	Power Cord	1	R-18	154868	500Ω ±10%, 2W, Wirewound .	18
C-10	159413	10μF, 50Vdc, Electrolytic.	74	Q-1	184574	Transistor 2N5366	74	R-19	153447	200Ω ±5%, 1/2W	75
C-11	160673	.68μF ±10%, 100Vdc	74	Q-2	184574	Transistor 2N5366	74	R-20	153447	200Ω ±5%, 1/2W	75
C-12	162883	60μF, 50Vdc, Electrolytic.	74	Q-3	166893	Transistor 2N217, 2N408, or 2N1370.	74	R-21	120506	15kΩ ±10%, 1/2W	75
C-13	159416	Capacitor	73	Q-4	184574	Transistor 2N5366	74	R-22	120508	68kΩ ±10%, 1/2W	75
C-14	159634	1300μF, 35Vdc, Electrolytic. ...	17	Q-5	166893	Transistor 2N217, 2N408, or 2N1370.	74	R-23	126903	22kΩ ±10%, 1/2W	75
C-15	159634	1300μF, 35Vdc, Electrolytic. ...	17	Q-6	170542	Transistor 2N1102.	74	R-24	159406	220Ω ±10%, 1/2W	75
C-16	159416	Capacitor	73	Q-7	159426	Transistor 2N307 or B10394. ...	72	R-25	159407	47Ω ±10%, 2W	73
C-17	161022	25μF, 10Vdc, Electrolytic.	74	Q-8	159426	Transistor 2N307 or B10394. ...	72	R-26	159633	25Ω ±10%, 25W	18
C-18	159418	100pF ±10%, 50Vdc.	74	QS-7	159422	Transistor Socket	72	R-27	159427	5kΩ Volume Control.	75
C-20	161020	.005μF ±10%, 50Vdc	74	QS-8	159422	Transistor Socket	72	R-28	159428	Bias Control, 500kΩ	75
C-21	159420	.004μF ±10%, 50Vdc	74	R-1	126101	470kΩ ±10%, 1/2W	75	R-29	154866	5.6kΩ ±10%, 1/2W	75
C-22	161021	.0018μF ±10%, 50Vdc	74	R-2	78671	47kΩ ±10%, 1/2W	75	R-30	120504	33kΩ ±10%, 1/2W	75
C-23	161021	.0018μF ±10%, 50Vdc	74	R-3	160558	3.6kΩ ±5%, 1/2W	75	R-31	160672	.25Ω ±10%, 1W, Wirewound ..	73
C-24	159418	100pF ±10%, 50Vdc.	74	R-4	126900	10kΩ ±10%, 1/2W	75	R-32	160672	.25Ω ±10%, 1W, Wirewound ..	75
C-25	159409	.027μF, 100Vdc	74	R-5	136709	47Ω ±10%, 1/2W	75	R-34	164603	Potentiometer, 25kΩ	72
C-26	159414	.033μF, 100Vdc	74	R-6	78671	47kΩ ±10%, 1/2W	75	S-1	186949	Input Selector Switch	72
C-27	159419	.047μF, 100Vdc	74	R-7	119816	1kΩ ±10%, 1/2W	75	S-2	159435	Tone Control Switch	74
C-29	159413	10μF, 50Vdc, Electrolytic.	74					S-3	159533	Projector Control Switch.	32
CB-1	151383	Circuit Breaker.	72					S-4	159445	Amplifier Control Switch.	72
CR-1	164193	750mA, 200PIV Diode	18					J-1		Threadlamp Socket	
CR-2	164193	750mA, 200PIV Diode	18					S-5	166142	Line Voltage Switch	15A
								S-6	162455	Line Frequency Switch	15A
								T-1	166139	Power Transformer	17

PART NUMBERS IN NUMERICAL ORDER

78671	R-2	126900	R-4	154866	R-29	159413	C-10	159426	Q-7	159551	P-1	161022	C-2	166142	S-5
78671	R-6	126900	R-8	154868	R-18	159413	C-29	159426	Q-8	159633	R-26	161022	C-4	166147	B-1
119816	R-7	126903	R-23	159406	R-14	159414	C-26	159427	R-27	159634	C-14	161022	C-17	166893	Q-3
119816	R-9	136709	R-5	159406	R-24	159416	C-13	159428	R-28	159634	C-15	162455	S-6	166893	Q-5
119816	R-15	145170	J-6	159407	R-25	159416	C-16	159429	J-3	160558	R-3	162883	C-12	168043	R-12
120504	R-30	147832	J-2	159408	C-5	159418	C-18	159429	J-5	160672	R-31	164193	CR-1	170542	Q-6
120506	R-21	151383	CB-1	159408	C-6	159418	C-24	159430	J-4	160672	R-32	164193	CR-2	184574	Q-1
120508	R-22	152129	C-3	159409	C-25	159419	C-27	159435	S-2	160673	C-11	164193	CR-3	184574	Q-2
126101	R-1	152753	R-10	159410	C-9	159420	C-21	159444	CR-5	161020	C-20	164193	CR-4	184574	Q-4
126394	R-11	153447	R-19	159411	C-7	159422	QS-7	159445	S-4, J-1	161021	C-22	164603	R-34	186949	S-1
126401	R-13	153447	R-20	159412	C-8	159422	QS-8	159533	S-3	1661021	C-23	166128	B-2	870569	R-16
										161022	C-1	166139	T-1	872379	R-17

AV-256-TR MODELS



Measure dc voltages with high impedance voltmeter with no input signal and no external load.

Numbers in circles refer to voltage check points.

SCHEMATIC CIRCUIT (FEBRUARY 1968)

CODE	PART NO.	DESCRIPTION	FIG.
B-1	159442	Motor and Bracket Assembly. . .	23
C-1	161022	25 μ F, 10Vdc, Electrolytic. . . .	78
C-2	161022	25 μ F, 10Vdc, Electrolytic. . . .	78
C-3	161858	.015 μ F, 50Vdc, Electrolytic. . .	78
C-4	161022	25 μ F, 10Vdc, Electrolytic. . . .	78
C-5	164758	40 μ F, 25Vdc, Electrolytic. . . .	78
C-6	161022	25 μ F, 10Vdc, Electrolytic. . . .	78
C-7	159413	10 μ F, 50Vdc, Electrolytic. . . .	78
C-8	159413	10 μ F, 50Vdc, Electrolytic. . . .	78
C-9	159410	125 μ F, 50Vdc, Electrolytic. . .	78
C-10	165556	25 μ F, 50Vdc, Electrolytic. . . .	78
C-11	161831	75 μ F, 6Vdc, Electrolytic. . . .	78
C-12	159410	125 μ F, 50Vdc, Electrolytic. . .	78
C-13	161832	Capacitor.	77
C-14	143229	.0015 μ F $\pm$ 10%, 450Vdc.	78
C-15	159416	Capacitor.	77
C-16	161022	25 μ F, 10Vdc, Electrolytic. . . .	78
C-17	161022	25 μ F, 10Vdc, Electrolytic. . . .	78
C-18	159634	1300 μ F, 35Vdc, Electrolytic. . .	19
C-19	159634	1300 μ F, 35Vdc, Electrolytic. . .	19
C-20	161020	.005 μ F $\pm$ 10%, 50Vdc.	78
C-21	159420	.004 μ F $\pm$ 10%, 50Vdc.	78
C-22	161021	.0018 μ F, 50Vdc.	78
C-23	161021	.0018 μ F, 50Vdc.	78
C-24	159418	100pF $\pm$ 10%, 50Vdc.	78
C-25	159409	.027 μ F, 100Vdc.	78
C-26	159414	.033 μ F, 100Vdc.	78
C-27	159419	.047 μ F, 100Vdc.	78
C-28	164758	40 μ F, 25Vdc, Electrolytic. . . .	78
C-29	159413	10 μ F, 50Vdc, Electrolytic. . . .	78
C-30	164757	.001 μ F $\pm$ 10%, 50Vdc.	77
C-31	164757	.001 μ F $\pm$ 10%, 50Vdc.	77
C-32	152129	.01 μ F $\pm$ 10%, 50Vdc.	77
CB-1	151383	Circuit Breaker.	76
CR-1	164193	750mA, 200PIV Diode.	20
CR-2	164193	750mA, 200PIV Diode.	20

CODE	PART NO.	DESCRIPTION	FIG.
CR-3	164193	750mA, 200PIV Diode.	20
CR-4	164193	750mA, 200PIV Diode.	20
DS-1		Projection Lamp.	26
DS-2		Photocell Exciter Lamp.	5
J-2	147832	Speaker Jack.	76
J-3	159429	Phono Jack.	76
J-4	159430	Microphone Connector.	76
J-5	159429	Solar Cell Jack.	76
J-6	145170	Projection Lamp Socket.	43
P-1	159551	Power Cord.	1
Q-1	184574	Transistor 2N5366.	78
Q-2	184574	Transistor 2N5366.	78
Q-3	184574	Transistor 2N5366.	78
Q-4	162893	Transistor 2N1038.	78
Q-5	161849	Transistor 2N1136.	78
Q-6	161835	Transistor 2N1136A.	76
Q-7	161835	Transistor 2N1136A.	76
QS-5	159422	Transistor Socket.	78
QS-6	159422	Transistor Socket.	76
QS-7	159422	Transistor Socket.	76
R-1	126101	470k Ω $\pm$ 10%, 1/2W.	79
R-2	78671	47k Ω $\pm$ 10%, 1/2W.	79
R-3	147756	1.8k Ω $\pm$ 10%, 1/2W.	79
R-4	126900	10k Ω $\pm$ 10%, 1/2W.	79
R-5	136709	47 Ω $\pm$ 10%, 1/2W.	79
R-6	78671	47k Ω $\pm$ 10%, 1/2W.	79
R-7	119816	1k Ω $\pm$ 10%, 1/2W.	79
R-8	126900	10k Ω $\pm$ 10%, 1/2W.	79
R-9	162891	27 Ω $\pm$ 5%, 1/2W.	79
R-10	112546	2.7k Ω $\pm$ 10%, 1/2W.	79
R-11	162892	33 Ω $\pm$ 5%, 1/2W.	79
R-12	168066	39k Ω $\pm$ 5%, 1/2W.	79
R-13	160123	680 Ω $\pm$ 5%, 1/2W.	79

CODE	PART NO.	DESCRIPTION	FIG.
R-14	123301	1.1k Ω $\pm$ 5%, 1/2W.	79
R-15	126905	27k Ω $\pm$ 10%, 1/2W.	79
R-16	866521	390 Ω $\pm$ 10%, 1/2W.	79
R-17	872379	1.2k Ω $\pm$ 10%, 1/2W.	79
R-18	165557	600 Ω $\pm$ 5%, 5W, Wirewound. .	79
R-19	161827	91 Ω $\pm$ 5%, 1W.	79
R-20	127852	300 Ω $\pm$ 10%, 5W, Wirewound. .	79
R-21	872443	12k Ω $\pm$ 10%, 1/2W.	79
R-22	126900	10k Ω $\pm$ 10%, 1/2W.	79
R-23	161828	18 Ω $\pm$ 10%, 1/2W.	79
R-24	126900	10k Ω $\pm$ 10%, 1/2W.	79
R-25	161829	Bias Control.	79
R-26	147756	1.8k Ω $\pm$ 10%, 1/2W.	79
R-27	178372	Volume Control.	79
R-28	161830	1 Ω $\pm$ 5%, 2W, Wirewound. . . .	77
R-29	161830	1 Ω $\pm$ 5%, 2W, Wirewound. . . .	79
R-30	159633	25 Ω $\pm$ 10%, 25W.	20
R-31	126394	4.7k Ω $\pm$ 10%, 1/2W.	79
R-32	78671	47k Ω $\pm$ 10%, 1/2W.	79
R-33	147756	1.8k Ω $\pm$ 10%, 1/2W.	79
R-34	872378	100 Ω $\pm$ 10%, 1/2W.	79
R-35	161828	18 Ω $\pm$ 10%, 1/2W.	79
R-36	126901	6.8k Ω $\pm$ 10%, 1/2W.	79
R-37	872443	12k Ω $\pm$ 10%, 1/2W.	79
R-38	112546	2.7k Ω $\pm$ 10%, 1/2W.	79
R-39	154868	500 Ω $\pm$ 10%, 2W.	20
R-40	161857	Control—Frequency Response. .	79
R-41	164603	Potentiometer, 25k Ω	76
R-42	154868	500 Ω $\pm$ 10%, 2W, Wirewound. .	77
S-1	186949	Input Selector Switch.	76
S-2	159435	Tone Control Switch.	79
S-3	159533	Projector Control Switch.	32
S-4	159445	Amplifier Control Switch.	76
J-1		Threadlamp Socket.	
T-1	161836	Driver Transformer.	78
T-2	161837	Power Transformer.	19

PART NUMBERS IN NUMERICAL ORDER

NUMBER	CODE
78671	R-2
78671	R-6
78671	R-32
112546	R-10
112546	R-38
119816	R-7
123301	R-14
126101	R-1
126394	R-31
126900	R-4
126900	R-8
126900	R-22
126900	R-24

NUMBER	CODE
126901	R-36
126905	R-15
127852	R-20
136709	R-5
143229	C-14
145170	J-6
147756	R-3
147756	R-26
147756	R-33
147832	J-2
151383	CB-1
152129	C-32
154868	R-39

NUMBER	CODE
154868	R-42
159409	C-25
159410	C-9
159410	C-12
159413	C-7
159413	C-8
159413	C-29
159414	C-26
159416	C-15
159418	C-24
159419	C-27
159420	C-21
159422	QS-5

NUMBER	CODE
159422	QS-6
159422	QS-7
159429	J-3
159429	J-5
159430	J-4
159435	S-2
159442	B-1
159445	S-4, J-1
159533	S-3
159551	P-1
159633	R-30
159634	C-18
159634	C-19


NUMBER	CODE
160123	R-13
161020	C-20
161021	C-22
161021	C-23
161022	C-1
161022	C-2
161022	C-4
161022	C-6
161022	C-16
161022	C-17
161827	R-19
161828	R-23
161828	R-35

NUMBER	CODE
161829	R-25
161830	R-28
161830	R-29
161831	C-11
161832	C-13
161835	Q-6
161835	Q-7
161836	T-1
161837	T-2
161849	Q-5
161857	R-40
161858	C-3
162891	R-9

NUMBER	CODE
162892	R-11
162893	Q-4
164193	CR-1
164193	CR-2
164193	CR-3
164193	CR-4
164603	R-41
164757	C-30
164757	C-31
164758	C-5
164758	C-28
165556	C-10

NUMBER	CODE
165557	R-18
168066	R-12
178372	R-27
184574	Q-1
184574	Q-2
184574	Q-3
186949	S-1
866521	R-16
872378	R-34
872379	R-17
872443	R-21
872443	R-37

AV-256-TR-R MODELS



Measure dc voltages with high impedance voltmeter with no input signal and no external load.

Numbers in circles refer to voltage check points.

SCHEMATIC CIRCUIT (FEBRUARY 1968)

CODE	PART NO.	DESCRIPTION	FIG.	CODE	PART NO.	DESCRIPTION	FIG.	CODE	PART NO.	DESCRIPTION	FIG.
B-1	166147	Motor and Bracket Assembly...	22	CR-2	164193	750mA, 200PIV Diode.....	20	R-14	123301	1.1kΩ ±5%, 1/2W.....	79
B-2	166128	Blower Motor and Bracket Assembly.....	25	CR-3	164193	750mA, 200PIV Diode.....	20	R-15	126905	27kΩ ±10%, 1/2W.....	79
C-1	161022	25μF, 10Vdc, Electrolytic.....	78	CR-4	164193	750mA, 200PIV Diode.....	20	R-16	866521	390Ω ±10%, 1/2W.....	79
C-2	161022	25μF, 10Vdc, Electrolytic.....	78	DS-1		Projection Lamp.....	26	R-17	872379	1.2kΩ ±10%, 1/2W.....	79
C-3	161858	.015μF, 50Vdc, Electrolytic.....	78	DS-2		Photocell Exciter Lamp.....	5	R-18	165557	600Ω ±5%, 5W, Wirewound..	79
C-4	161022	25μF, 10Vdc, Electrolytic.....	78	J-2	147832	Speaker Jack.....	76	R-19	161827	91Ω ±5%, 1W.....	79
C-5	164758	40μF, 25Vdc, Electrolytic.....	78	J-3	159429	Phono Jack.....	76	R-20	127852	300Ω ±10%, 5W, Wirewound..	79
C-6	161022	25μF, 10Vdc, Electrolytic.....	78	J-4	159430	Microphone Connector.....	76	R-21	872443	12kΩ ±10%, 1/2W.....	79
C-7	159413	10μF, 50Vdc, Electrolytic.....	78	J-5	159429	Solar Cell Jack.....	76	R-22	126900	10k ±10%, 1/2W.....	79
C-8	159413	10μF, 50Vdc, Electrolytic.....	78	J-6	145170	Projection Lamp Socket.....	43	R-23	161828	18Ω ±10%, 1/2W.....	79
C-9	159410	125μF, 50Vdc, Electrolytic.....	78	P-1	159551	Power Cord.....	1	R-24	126900	10kΩ ±10%, 1/2W.....	79
C-10	165556	25μF, 50Vdc, Electrolytic.....	78	Q-1	184574	Transistor 2N5366.....	78	R-25	161829	Bias Control.....	79
C-11	161831	75μF, 6Vdc, Electrolytic.....	78	Q-2	184574	Transistor 2N5366.....	78	R-26	147756	1.8kΩ ±10%, 1/2W.....	79
C-12	159410	125μF, 50Vdc, Electrolytic.....	78	Q-3	184574	Transistor 2N5366.....	78	R-27	178372	Volume Control.....	79
C-13	161832	Capacitor.....	77	Q-4	162893	Transistor 2N1038.....	78	R-28	161830	1Ω ±5%, 2W, Wirewound.....	77
C-14	143229	.0015pF ±10%, 450Vdc.....	78	Q-5	161849	Transistor 2N1136.....	78	R-29	161830	1Ω ±5%, 2W, Wirewound.....	79
C-15	159416	Capacitor.....	77	Q-6	161835	Transistor 2N1136A.....	76	R-30	159633	25Ω ±10%, 25W.....	20
C-16	161022	25μF, 10Vdc, Electrolytic.....	78	Q-7	161835	Transistor 2N1136A.....	76	R-31	126394	4.7kΩ ±10%, 1/2W.....	79
C-17	161022	25μF, 10Vdc, Electrolytic.....	78	QS-5	159422	Transistor Socket.....	76	R-32	78671	47kΩ ±10%, 1/2W.....	79
C-18	159634	1300μF, 35Vdc, Electrolytic...	19	QS-6	159422	Transistor Socket.....	76	R-33	147756	1.8kΩ ±10%, 1/2W.....	79
C-19	159634	1300μF, 35Vdc, Electrolytic...	19	QS-7	159422	Transistor Socket.....	76	R-34	872378	100Ω ±10%, 1/2W.....	79
C-20	161020	.005μF ±10%, 50Vdc.....	78	R-1	126101	470kΩ ±10%, 1/2W.....	79	R-35	161828	18Ω ±10%, 1/2W.....	79
C-21	159420	.004μF ±10%, 50Vdc.....	78	R-2	78671	47kΩ ±10%, 1/2W.....	79	R-36	126901	6.8kΩ ±10%, 1/2W.....	79
C-22	161021	.0018μF, 50Vdc.....	78	R-3	147756	1.8kΩ ±10%, 1/2W.....	79	R-37	872443	12kΩ ±10%, 1/2W.....	79
C-23	161021	.0018μF, 50Vdc.....	78	R-4	126900	10kΩ ±10%, 1/2W.....	79	R-38	112546	2.7kΩ ±10%, 1/2W.....	79
C-24	159418	100pF ±10%, 50Vdc.....	78	R-5	136709	47Ω ±10%, 1/2W.....	79	R-39	154868	500Ω ±10%, 2W.....	20
C-25	159409	.027μF, 100Vdc.....	78	R-6	78671	47kΩ ±10%, 1/2W.....	79	R-40	161857	Control—Frequency Response..	79
C-26	159414	.033μF, 100Vdc.....	78	R-7	119816	1kΩ ±10%, 1/2W.....	79	R-41	164603	Potentiometer, 25kΩ.....	76
C-27	159419	.047μF, 100Vdc.....	78	R-8	126900	10kΩ ±10%, 1/2W.....	79	R-42	154868	500Ω ±10%, 2W, Wirewound..	77
C-28	164758	40μF, 25Vdc, Electrolytic.....	78	R-9	162891	27Ω ±5%, 1/2W.....	79	S-1	186949	Input Selector Switch.....	76
C-29	159413	10μF, 50Vdc, Electrolytic.....	78	R-10	112546	2.7kΩ ±10%, 1/2W.....	79	S-2	159435	Tone Control Switch.....	79
C-30	164757	.001μF ±10%, 50Vdc.....	77	R-11	162892	33Ω ±5%, 1/2W.....	79	S-3	159533	Projector Control Switch.....	32
C-31	164757	.001μF ±10%, 50Vdc.....	77	R-12	168066	39kΩ ±5%, 1/2W.....	79	S-4	159445	Amplifier Control Switch.....	76
C-32	152129	.01μF ±10%, 50Vdc.....	77	R-13	160123	680Ω ±5%, 1/2W.....	79	J-1		Threadlamp Socket.....	
CB-1	151383	Circuit Breaker.....	76					S-5	166142	Line Voltage Switch.....	15A
CR-1	164193	750mA, 200PIV Diode.....	20					S-6	162455	Line Frequency Switch.....	15A
								T-1	161836	Driver Transformer.....	78
								T-2	166437	Power Transformer.....	19

PART NUMBERS IN NUMERICAL ORDER

NUMBER	CODE	NUMBER	CODE	NUMBER	CODE	NUMBER	CODE	NUMBER	CODE	NUMBER	CODE	NUMBER	CODE	NUMBER	CODE
78671	R-2	126901	R-36	154868	R-42	159422	QS-6	161020	C-20	161830	R-28	162893	Q-4	166142	S-5
78671	R-6	126905	R-15	159409	C-25	159422	QS-7	161021	C-22	161830	R-29	164193	CR-1	166147	B-1
78671	R-32	127852	R-20	159410	C-9	159429	J-3	161021	C-23	161831	C-11	164193	CR-2	166437	T-2
112546	R-10	136709	R-5	159410	C-12	159429	J-5	161022	C-1	161832	C-13	164193	CR-3	168066	R-12
112546	R-38	143229	C-14	159413	C-7	159430	J-4	161022	C-2	161835	Q-6	164193	CR-4	178372	R-27
119816	R-7	145170	J-6	159413	C-8	159435	S-2	161022	C-4	161835	Q-7	164603	R-41	184574	Q-1
123301	R-14	147756	R-3	159413	C-29	159445	S-4, J-1	161022	C-6	161836	T-1	164757	C-30	184574	Q-2
126101	R-1	147756	R-26	159414	C-26	159533	S-3	161022	C-16	161849	Q-5	164757	C-31	184574	Q-3
126394	R-31	147756	R-33	159416	C-15	159551	P-1	161022	C-17	161857	R-40	164758	C-5	186949	S-1
126900	R-4	147832	J-2	159418	C-24	159633	R-30	161827	R-19	161858	C-3	164758	C-28	866521	R-16
126900	R-8	151383	CB-1	159419	C-27	159634	C-18	161828	R-23	162455	S-6	165556	C-10	872378	R-34
126900	R-22	152129	C-32	159420	C-21	159634	C-19	161828	R-35	162891	R-9	165557	R-18	872379	R-17
126900	R-24	154868	R-39	159422	QS-5	160123	R-13	161829	R-25	162892	R-11	166128	B-2	872443	R-21
														872443	R-37

Customer Equipment Services Division
EASTMAN KODAK COMPANY • ROCHESTER, N. Y. 14650