


Canon

REMOTE SWITCH RS-80N3

C58-5631

**PARTS
CATALOG**

CANON REMOTE SWITCH RS-80N3



PARTS LIST

REF.No.C58-5631

NEW	PARTS NO.	CLASS	QTY	DESCRIPTION
	CA4-3995-000	E	2	SPACER, CONTACT
	CA4-3996-000	E	1	CONTACT, RELEASE GROUND
	CA4-3997-000	E	1	CONTACT, RELEASE SWITCH
	CA4-3998-000	E	1	CONTACT, RELEASE SWITCH
	CB4-0433-000	E	1	BUTTON, RELEASE
	CB4-0434-000	E	1	PLATE, RELEASE BASE
	CB4-0435-000	E	1	SHEET, LOCK MARK
	CB4-0436-000	E	1	COVER, UNDER
	CB4-0437-000	E	1	COVER, TOP
	CF4-0819-000	D	1	CORD, 3P PLUG
	CS1-7328-000	E	1	PLATE, RELEASE LOCK
	XA4-6170-307	E	1	SCREW
	XA4-6170-707	E	2	SCREW
	XA4-6170-709	E	2	SCREW