

## ***IMPORTANT TERMS INTRODUCED IN THE CAMERA AND ITS VARIATIONS\****

Aperture	Infinity	Rewind button
Bellows	Instant-return mirror	Rewind knob
Blackout	Invert	Roll-film camera
Box camera	Iris diaphragm	Sheet film
Bulb setting	Lens	Shutter
Camera obscura	Lens board	Shutter speed
Cartridge cassette	Lens standard	Shutter-speed control
Dark slide	Lighten-darken control	Shutter-speed scale
Depth of field	Magnifier	Single-frame camera
Develop	Medium-format camera	Single-lens reflex
Diaphragm	Metering	Split-image focusing aid
Diaphragm control	Microprism focusing aid	Split-image rangefinder
Diaphragm opening	Miniature camera	Sprocket
Diaphragm scale	Mirror	Subminiature camera
Double-frame camera	Mirror cage	Superimposed-image
Eye-level viewing	Mirror-lock-up control	rangefinder
F/number or f/stop	Motor drive	Supply chamber
Film	Parallax	System
Film back	Pentaprism	Transmission stop or T/stop
Film-holding mechanism	Perforation holes	Take-up chamber
Film insert	Perspective distortion	Take-up spool
Film leader	Pin hole	Thumb slide
Film pack	Plate	Time setting
Fixed-focus lens	Pocket Instamatic	Twin-lens reflex
Focal-plane aperture	Polaroid back	Underwater camera
Focusing aid	Press camera	View camera
Focusing control	Press-focus lever	Viewfinder
Focusing scale	Process camera	Viewfinder-type camera
Focusing screen	Prism	Waist-level viewing
Frame lines	Rangefinder	Waterhouse stop
Fresnel lens	Rangefinder-type camera	Wind crank
Full-frame camera	Rapid-rewind crank	Wind lever
Ground glass	Release button	Zone focusing
Half-frame camera	Revert	
Hood	Rewind	

\*Use this page of terms as a check-list to test yourself on how thoroughly you have absorbed the text material. If the definition for a particular term does not come immediately to mind, additional study is indicated.